

```

EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEE                                     RRR   FFF
EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF
EEEEEEEEEEEEEEEEEE   RRRRRRRRRRRR   FFFFFFFFFFFFFFFF

```

[illegible]

```

MM      MM      EEEEEEEEEEE      MM      MM      000000      RRRRRRRR      YY      YY      SSSSSSSS
MM      MM      EEEEEEEEEEE      MM      MM      000000      RRRRRRRR      YY      YY      SSSSSSSS
MMM     MMM     EE      MMM     MMM     00      00      RR      RR      YY      YY      SS
MMM     MMM     EE      MMM     MMM     00      00      RR      RR      YY      YY      SS
MM      MM      EE      MM      MM      00      00      RR      RR      YY      YY      SS
MM      MM      EE      MM      MM      00      00      RR      RR      YY      YY      SS
MM      MM      EEEEEEEEE      MM      MM      00      00      RRRRRRRR      YY      YY      SSSSSS
MM      MM      EEEEEEEEE      MM      MM      00      00      RRRRRRRR      YY      YY      SSSSSS
MM      MM      EE      MM      MM      00      00      RR      RR      YY      YY      SS
MM      MM      EE      MM      MM      00      00      RR      RR      YY      YY      SS
MM      MM      EE      MM      MM      00      00      RR      RR      YY      YY      SS
MM      MM      EE      MM      MM      00      00      RR      RR      YY      YY      SS
MM      MM      EEEEEEEEEEE      MM      MM      000000      RR      RR      YY      YY      SSSSSSSS
MM      MM      EEEEEEEEEEE      MM      MM      000000      RR      RR      YY      YY      SSSSSSSS

LL      IIIIII      SSSSSSSS
LL      IIIIII      SSSSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SSSSSS
LL      II      SSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LLLLLLLLLLLL      IIIIII      SSSSSSSS
LLLLLLLLLLLL      IIIIII      SSSSSSSS
    
```

1 2  
16-Sep-1984 00:07:33  
5-Sep-1984 14:01:18

VAX-11 FORTRAN V3.4-56 Page 1  
DISK\$VMSMASTER:[ERF.SRC]MEMORYS.FOR;1

```
0001 C
0002 C Version: 'V04-000'
0003 C
0004 C*****
0005 C*
0006 C* COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0007 C* DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0008 C* ALL RIGHTS RESERVED.
0009 C*
0010 C* THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0011 C* ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0012 C* INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0013 C* COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0014 C* OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0015 C* TRANSFERRED.
0016 C*
0017 C* THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0018 C* AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0019 C* CORPORATION.
0020 C*
0021 C* DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0022 C* SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0023 C*
0024 C*
0025 C*****
0026 C
0027 C
0028 C Author Brian Porter Creation Date 30-DEC-1980
0029 C
0030 C Modified by:
0031 C
0032 C V03-012 SAR0258 Sharon A. Reynolds 25-Apr-1984
0033 C - Fixed a problem in the micro vax memory support.
0034 C - Added an sye update that adds decoding for
0035 C MA780 pcsr.
0036 C
0037 C V03-011 SAR0246 Sharon A. Reynolds, 9-Apr-1984
0038 C Added micro vax memory support.
0039 C
0040 C V03-010 SAR0202 Sharon A. Reynolds, 27-Feb-1984
0041 C Added the MEMORY_REGISTER_UV1 routine. Because memory
0042 C support for the micro vax is not ready it will output a
0043 C message. This was done so that the link of ERF would not
0044 C fail.
0045 C
0046 C V03-009 SAR0178 Sharon A. Reynolds, 30-Nov-1983
0047 C Fixed the entry headers for 11/750 and 11/730 memories.
0048 C
0049 C V03-008 SAR0169 Sharon A. Reynolds, 28-Oct-1983
0050 C Added an SYE update that:
0051 C - Modified MS780E reporting to weight array numbers
0052 C of the second controller by 8.
0053 C - Also added code to count multiple errors being
0054 C logged by one controller.
0055 C
0056 C V03-007 SAR0083 Sharon A. Reynolds, 20-Jun-1983
0057 C Changed the carriage control in the 'format' statements
```

for use with ERF.

v03-006 SAR0058 Sharon A. Reynolds, 2-Jun-1983  
Made 'memory\_display' a subroutine and added a routine  
that gets the necessary queue information so that 'memory\_q'  
and 'memory\_display' can be linked with separate images.  
Removed brief and cryptic code.

v03-005 BP0005 Brian Porter, 14-APR-1983  
11/730 syndrome bits are inverted so...

v03-004 BP0004 Brian Porter, 08-MAR-1983  
Corrected 11/730 memory size.

v03-003 BP0003 Brian Porter, 09-NOV-1982  
Corrected bank value for m8750 memories.

v03-002 BP0002 Brian Porter, 13-AUG-1982  
Corrected ms780e memory start address.

v03-001 BP0001 Brian Porter, 04-APR-1982  
Corrected output conversion error.

Subroutine MEMORY (lun,option)

Functional description:

This module extracts the varies arguments from the memory error  
entry and calls memory\_q. The format of a memory error entry is as  
follows. The area occupied by the adaptor TR and registers is  
repeated for the 'number of controllers' times. The register area  
size is dependent on the memory controller of the system being logged.  
The error pc and error psl are manufactured by VMS and have no meaning,  
therefore they are not printed in any of the reports.

```

+-----+
| header space |
+-----+
| number of controllers |
| adaptor tr# (or equivalent) |
+-----+
| memory registers |
+-----+

```

0115  
0116  
0117  
0118  
0119  
0120  
0121  
0122  
0123  
0124  
0125  
0126  
0127  
0128  
0129  
0130  
0131  
0132  
0133  
0134  
0135  
0136  
0137  
0138  
0139  
0140  
0141  
0142  
0143  
0144  
0145  
0146  
0147  
0148  
0149  
0150  
0151  
0152  
0153  
0154  
0155  
0156  
0157  
0158  
0159  
0160  
0161  
0162  
0163  
0164  
0165  
0166  
0167  
0168  
0169  
0170  
0171  
0172  
0173

C  
C  
C  
C  
C  
C  
C--

```

+-----+
|               |
|               |
|               |
|               |
|               |
|               |
|               |
|               |
|               |
|               |
+-----+

```

```

include 'src$:msghdr.for /nolist'
include 'src$:syecom.for /nolist'

```

```

byte          lun
character*1    option
integer*4      buffer(0:120)
integer*4      controller_count
integer*4      i
integer*4      lib$extzv
integer*4      compress4
integer*4      error_array
integer*4      error_bank
integer*4      error_bit
integer*4      page_count
integer*4      array_code
integer*4      decode_ecc

equivalence    (emb(16),buffer)
equivalence    (buffer(0),controller_count)

logical*1      l0011
logical*1      l0016

```

```

if (
1 lib$extzv(24,8,emb$l_hd_sid) .eq. 255
1 .or.
1 lib$extzv(24,8,emb$l_hd_sid) .eq. 1
1 ) then
j = 0
do 20,i = 1,controller_count
if (option .ne. 'R'
1 .and.
1 j .eq. 0) then
call header (lun)
if (emb$u_hd_entry .eq. 5) then
call logger (lun,'SBI ALERT')

```

MA71  
0111  
0112  
0113  
0114  
0115  
0116  
0117  
0118  
0119  
0120  
0121  
0122  
0123  
0124  
0125  
0126  
0127  
0128  
0129  
0130  
0131  
0132  
0133  
0134  
0135  
0136  
0137  
0138  
0139  
0140  
0141  
0142  
0143  
0144  
0145  
0146  
0147  
0148  
0149  
0150  
0151  
0152  
0153  
0154  
0155  
0156  
0157  
0158  
0159  
0160  
0161  
0162  
0163  
0164  
0165  
0166  
0167  
0168  
0169  
0170  
0171  
0172  
0173

```

0357     else if (emb$w_hd_entry .eq. 8) then
0358
0359     call logger (lun,'FATAL MEMORY ERROR')
0360     else
0361
0362     call logger (lun,'MEMORY ERROR')
0363     endif
0364     endif
0365
0366
0367 C
0368 C
0369 C      MS780C
0370     if (lib$extzv(5,3,buffer(2 + j)) .eq. 0) then
0371
0372     if (emb$w_hd_entry .ne. '05'x) then
0373
0374     if (lib$extzv(28,1,buffer(4 + j)) .eq. 1) then
0375
0376     if (lib$extzv(4,1,buffer(2 + j)) .eq. 0) then
0377
0378     call memory_g (emb$l_hd_sid,buffer(1 + j),
0379     1 lib$extzv(24,4,buffer(4 + j)),lib$extzv(21,1,buffer(4+j)),
0380     1 decode_ecc(lib$extzv(0,8,buffer(4 + j)),buffer(2 + j)))
0381
0382     else if (lib$extzv(4,1,buffer(2 + j)) .eq. 1) then
0383
0384     call memory_g (emb$l_hd_sid,buffer(1 + j),
0385     1 lib$extzv(24,4,buffer(4 + j)),lib$extzv(23,1,buffer(4+j)),
0386     1 decode_ecc(lib$extzv(0,8,buffer(4 + j)),buffer(2 + j)))
0387     endif
0388     endif
0389     endif
0390
0391 C
0392 C Full report output the TR# and call the MS780C routine to
0393 C decode/output the remainder of the entry.
0394 C
0395     if (option .eq. 'S') then
0396
0397     call linchk (lun,2)
0398
0399     write(lun,10) buffer(1 + j)
0400 10    format('/',',','CONTROLLER AT TR #',i<compress4 (buffer(1 + j))>,'.')
0401
0402     call ms780c (lun,buffer(2 + j))
0403     endif
0404
0405
0406     j = j + 4
0407
0408
0409 C
0410 C
0411 C      MS780E
0412     else if (lib$extzv(5,3,buffer(2 + j)) .eq. 3) then
0413

```

```

0173
0174
0175
0176
0177
0178
0179
0180
0181
0182
0183
0184
0185
0186
0187
0188
0189
0190
0191
0192
0193
0194
0195
0196
0197
0198
0199
0200
0201
0202
0203
0204
0205
0206
0207
0208
0209
0210
0211
0212
0213
0214
0215
0216
0217
0218
0219
0220
0221
0222
0223
0224
0225
0226
0227
0228
0229

```

```

0414      if (emb$w_hd_entry .ne. '05'x) then
0415
0416      if (lib$extzv(28,1,buffer(4 + j)) .eq. 1) then
0417
0418      call memory_q (emb$l_hd_sid,buffer(1 + j),
0419      1 lib$extzv(24,3,buffer(4 + j)),lib$extzv(22,2,buffer(4+j)),
0420      1 decode_ecc(lib$extzv(0,7,buffer(4 + j)),buffer(2 + j)))
0421      Endif
0422
0423      If (lib$extzv(28,1,buffer(5 + j)) .eq. 1) then
0424
0425      call memory_q (emb$l_hd_sid,buffer(1 + j),
0426      1 (lib$extzv(24,3,buffer(5 + j))+8),lib$extzv(22,2,buffer(5+j)),
0427      1 decode_ecc(lib$extzv(0,7,buffer(5 + j)),buffer(2 + j)))
0428      Endif
0429
0430      If (
0431      1 lib$extzv(18,2,buffer(2 + j)) .ne. 0
0432      1 .or.
0433      1 lib$extzv(7,1,buffer(3 + j)) .eq. 1
0434      1 .or.
0435      1 lib$extzv(7,1,buffer(4 + j)) .eq. 1
0436      1 .or.
0437      1 lib$extzv(7,1,buffer(5 + j)) .eq. 1
0438      1 ) then
0439
0440      call memory_q (emb$l_hd_sid,buffer(1 + j),-1,-1,-1)
0441      endif
0442      endif
0443
0444      C
0445      C Full report output the TR# and call the MS780E routine to
0446      C decode/output the remainder of the entry.
0447      C
0448      if (option .eq. 'S') then
0449
0450      call linchk (lun,2)
0451      write(lun,10) buffer(1 + j)
0452
0453      call ms780e (lun,buffer(2 + j))
0454      endif
0455
0456
0457      j = j + 5
0458
0459      C
0460      C MA780
0461      C
0462      else if (lib$extzv(5,3,buffer(2 + j)) .eq. 2) then
0463
0464      if (emb$w_hd_entry .ne. '05'x) then
0465
0466      if (lib$extzv (28,1,buffer(6 + j)) .eq. 1) then
0467
0468      call memory_q (emb$l_hd_sid,buffer(1 + j),
0469      1 lib$extzv(24,4,buffer(6 + j)),lib$extzv(23,1,buffer(6+j)),
0470      1 decode_ecc(lib$extzv(0,8,buffer(6 + j)),buffer(2 + j)))

```

```

0230
0231
0232
0233
0234
0235
0236
0237
0238
0239
0240
0241
0242
0243
0244
0245
0246
0247
0248
0249
0250
0251
0252
0253
0254
0255
0256
0257
0258
0259
0260
0261
0262
0263
0264
0265
0266
0267
0268
0269
0270
0271
0272
0273
0274
0275
0276
0277
0278
0279
0280
0281
0282
0283
0284
0285
0286

```

```
0471      Endif
0472
0473      If (
0474      1 lib$extzv(26,6,buffer(3 + j)) .ne. 0
0475      1 .or.
0476      1 lib$extzv(14,2,buffer(4 + j)) .ne. 0
0477      1 .or.
0478      1 lib$extzv(28,1,buffer(4 + j)) .eq. 1
0479      1 .or.
0480      1 lib$extzv(30,2,buffer(4 + j)) .ne. 0
0481      1 .or.
0482      1 lib$extzv(31,1,buffer(6 + j)) .eq. 1
0483      1 ) then
0484
0485      call memory_q (emb$l_hd_sid,buffer(1 + j),-1,-1,-1)
0486      endif
0487      endif
0488
0489      C
0490      C Full report output the TR# and call the MA780 routine to
0491      C decode/output the remainder of the entry.
0492      C
0493      if (option .eq. 'S') then
0494
0495      call linchk (lun,2)
0496      write(lun,10) buffer(1 + j)
0497
0498      call ma780 (lun,buffer(2 + j))
0499      endif
0500
0501      j = j + 9
0502      endif
0503
0504      20      continue
0505
0506      C
0507      C
0508      C
0509      C
0510      else if (lib$extzv(24,8,emb$l_hd_sid) .eq. 2) then
0511
0512      If (option .eq. 'S'
0513      1 .OR.
0514      2 option .eq. 'R') then
0515
0516      error_array = lib$extzv(9,15,buffer(2))
0517
0518      l0011 = .false.
0519
0520      l0016 = .false.
0521
0522      if (jand(buffer(4),'01000000'x) .ne. 0) then
0523
0524      l0016 = .true.
0525      else
0526
0527      l0011 = .true.
```

```
0287
0288
0289
0290
0291
0292
0293
0294
0295
0296
0297
0298
0299
0300
0301
0302
0303
0304
0305
0306
0307
0308
0309
0310
0311
0312
0313
0314
0315
0316
0317
0318
0319
0320
0321
0322
0323
0324
0325
0326
0327
0328
0329
0330
0331
0332
0333
0334
0335
0336
0337
0338
0339
0340
0341
0342
0343
```

```
0528      endif
0529
0530      do 30,i = 0,15,2
0531
0532      array_code = lib$extzv(i,2,buffer(4))
0533
0534      if (l0016) then
0535
0536      if (array_code .eq. 3) then
0537
0538      error_array = error_array - 512
0539
0540      if (lib$extzv(17,1,buffer(2)) .eq. 0) then
0541
0542      error_bank = 0
0543      else
0544
0545      error_bank = 1
0546      endif
0547
0548      else if (array_code .eq. 2) then
0549
0550      error_array = error_array - 2048
0551
0552      error_bank = lib$extzv(19,2,buffer(2))
0553      endif
0554
0555      else if (l0011) then
0556
0557      if (array_code .eq. 1) then
0558
0559      error_array = error_array - 256
0560
0561      error_bank = 0
0562
0563      else if (array_code .eq. 3) then
0564
0565      error_array = error_array - 512
0566
0567      if (lib$extzv(17,1,buffer(2)) .eq. 0) then
0568
0569      error_bank = 0
0570      else
0571
0572      error_bank = 1
0573      endif
0574      endif
0575      endif
0576
0577      if (error_array .le. 0) then
0578
0579      error_array = i/2
0580
0581      goto 40
0582      endif
0583
0584      30      continue
```

```

0585
0586 40      if (lib$extzv(29,1,buffer(2)) .eq. 1) then
0587
0588      call memory_q (emb$l_hd_sid,lib$extzv(0,3,buffer(1)),
0589      1 error_array,error_bank,decode_ecc(lib$extzv(0,7,buffer(2))))
0590
0591      else if (lib$extzv(31,1,buffer(2)) .eq. 1) then
0592
0593      call memory_q (emb$l_hd_sid,lib$extzv(0,3,buffer(1)),
0594      1 error_array,error_bank,-1)
0595      endif
0596      endif
0597
0598      If (option .NE. 'R') then
0599
0600      call header (lun)
0601
0602      If (emb$w_hd_entry .eq. 8) then
0603
0604      call logger (lun,'FATAL MEMORY ERROR')
0605      else
0606
0607      call logger (lun,'MEMORY ERROR')
0608      endif
0609      endif
0610
0611      if (option .eq. 'S') then
0612
0613      call linchk (lun,2)
0614      write(lun,50) lib$extzv(0,3,buffer(1))
0615 50      format('/',',','CONTROLLER AT SLOT INDEX #',
0616      1 i<compress4 (lib$extzv(0,3,buffer(1)))>','.')
0617
0618      call ms750 (lun,buffer(2))
0619      endif
0620
0621  C
0622  C      11/730
0623  C
0624      else if (lib$extzv(24,8,emb$l_hd_sid) .eq. 3) then
0625
0626      If (option .eq. 'S'
0627      1 .or.
0628      2 option .eq. 'R') then
0629  C
0630  C      11/730 syndrome bits are inverted so...
0631  C
0632
0633      error_bit = decode_ecc (lib$extzv(0,7,not(lib$extzv(0,7,buffer(0)))))
0634
0635      error_array = lib$extzv(9,15,buffer(0))
0636
0637      if (lib$extzv(24,1,buffer(2)) .eq. 1) then
0638
0639      page_count = 1024
0640      else
0641

```

•

[illegible]

Page 10

```

0699     else if (lib$extzv(24,8,emb$l_hd_sid) .eq. 7) then
0700         do 80,i = 1,16
0701             if (lib$extzv(15,1,buffer(i)) .eq. 1) then
0702                 call memory_q (emb$l_hd_sid,0,i,-1,-1)
0703             endif
0704         80 continue
0705         if (option .ne. 'C'
0706             1 .and.
0707             1 option .ne. 'R') then
0708             call header (lun)
0709             call logger (lun,'FATAL MEMORY ERROR')
0710         endif
0711         if (option .eq. 'S') then
0712             call memory_register_uv1 (lun,buffer(0))
0713         endif
0714     c
0715     c     The IF-THEN-ELSE should be expanded at this point to add
0716     c     additional CPU memory support.
0717     c
0718     endif
0719     return
0720 end
0721

```

## PROGRAM SECTIONS

Name	Bytes	Attributes									
0 \$CODE	2633	PIC	CON	REL	LCL	SHR	EXE	RD	NOWRT	LONG	
1 \$PDATA	218	PIC	CON	REL	LCL	SHR	NOEXE	RD	NOWRT	LONG	
2 \$LOCAL	928	PIC	CON	REL	LCL	NOSHR	NOEXE	RD	WRT	LONG	
3 EMB	512	PIC	OVR	REL	GBL	SHR	NOEXE	RD	WRT	LONG	
4 SYECOM	44	PIC	OVR	REL	GBL	SHR	NOEXE	RD	WRT	LONG	
Total Space Allocated		4335									

## ENTRY POINTS

Address	Type	Name
0-00000000		MEMORY

## VARIABLES

Address	Type	Name	Address	Type	Name
2-00000018	I*4	ARRAY_CODE	3-00000010	I*4	CONTROLLER_COUNT
4-00000012	L*1	CP_11750	4-00000011	L*1	CP_11780
4-00000013	L*1	CP_11722	4-00000014	L*4	CRYPTK_FLAG
4-0000000D	I*4	DEV_CHAR	3-00000000	I*4	EMBSL_HD_SID
3-00000004	I*2	EMBSW_HD_ENTRY	3-0000000E	I*2	EMBSW_HD_ERRSEQ
4-0000001E	L*1	END_VALUE	4-0000001D	L*1	EOF_FLAG
2-00000008	I*4	ERROR_ARRAY	2-0000000C	I*4	ERROR_BANK
2-00000010	I*4	ERROR_BIT	4-00000004	L*4	FORMS
2-00000004	I*4	I	2-0000001C	I*4	J
2-00000000	L*1	L0011	2-00000001	L*1	L0016
4-0000000C	L*1	LINES	4-00000027	I*4	LSTLUN
AP-00000004B	L*1	LUN	4-0000001F	I*4	MAILBOX_CHANNEL
AP-00000008B	CHAR	OPTION	4-0000002B	CHAR	OPTIONS
2-00000014	I*4	PAGE_COUNT	4-00000008	L*4	PRINTER
4-00000000	I*4	RECCNT	4-00000023	I*4	RECORD_SIZE
4-00000019	L*1	VALID_CLASS	4-0000001A	L*1	VALID_CPU
4-00000018	L*1	VALID_ENTRY	4-0000001C	L*1	VALID_TYPE
4-00000018	L*1	VOLUME_OUTPUT			

## ARRAYS

Address	Type	Name	Bytes	Dimensions
3-00000010	I*4	BUFFER	484	(0:120)
3-00000000	L*1	EMB	512	(0:511)
3-00000006	I*4	EMBSO_HD_TIME	8	(2)

MEMORY

G 3  
16-Sep-1984 00:07:33  
5-Sep-1984 14:01:18

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:[ERF.SRC]MEMORY.S.FOR;1  
Page 12

LABELS

Address	Label	Address	Label	Address	Label	Address	Label	Address	Label
1-0000008E	10'	**	20	**	30	0-0000075C	40	1-000000B0	50'
0-000008FC	65	**	80					**	60

FUNCTIONS AND SUBROUTINES REFERENCED

Type	Name	Type	Name	Type	Name
I*4	COMPRESS4	I*4	DECODE_ECC		HEADER
I*4	LIB\$EXTZV		LINCHK		LOGGER
	MA780		MEMORY_Q		MEMORY_REGISTER_UV1
	MS730		MS750		MS780C
	MS780E				

0002  
0003  
0004  
0005  
0006  
0007  
0008  
0009  
0010  
0011  
0012  
0013  
0014  
0015  
0016  
0017  
0018  
0019  
0020  
0021  
0022  
0023  
0024  
0025  
0026  
0027  
0028  
0029  
0030  
0031  
0032  
0033  
0034  
0035  
0036  
0037  
0038  
0039  
0040  
0041  
0042  
0043  
0044  
0045  
0046  
0047  
0048  
0049  
0050  
0051  
0052  
0053  
0054  
0055  
0056  
0057  
0058

0001

H 3  
16-Sep-1984 00:07:33  
5-Sep-1984 14:01:18

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:LERF.SRCJMEMORYS.FOR;1

Page 13

MS78

0059  
0060  
0061  
0062  
0063  
0064  
0065  
0066  
0067  
0068  
0069  
0070  
0071  
0072  
0073  
0074  
0075  
0076  
0077  
0078  
0079  
0080  
0081  
0082  
0083  
0084  
0085  
0086  
0087  
0088  
0089  
0090  
0091  
0092  
0093  
0094  
0095  
0096  
0097  
0098  
0099  
0100  
0101  
0102  
0103  
0104  
0105  
0106  
0107  
0108  
0109  
0110  
0111  
0112  
0113  
0114  
0115

# Subroutine MA780 (lun,memory\_registers)

This routine displays the ma780 memory registers.  
The format of the multi-port memory sub packet is as follows.

```

+-----+
| port configuration register |
+-----+
| port interface control register |
+-----+
| port controller status register |
+-----+
| port invalidation control reg |
+-----+
| array error register |
+-----+
| configuration status register 0 |
+-----+
| configuration status register 1 |
+-----+
| maintenance control register |
+-----+

```

Implicit	none
byte	lun
integer*4	memory_registers
integer*4	buffer(8)
integer*4	port_configuration_register
integer*4	port_interface_control_register
integer*4	port_controller_status_register
integer*4	port_invalidation_control_reg
integer*4	array_error_register
integer*4	configuration_status_register0
integer*4	configuration_status_register1
integer*4	maintenance_control_register
equivalence	(buffer(1),port_configuration_register)
equivalence	(buffer(2),port_interface_control_register)
equivalence	(buffer(3),port_controller_status_register)
equivalence	(buffer(4),port_invalidation_control_reg)
equivalence	(buffer(5),array_error_register)
equivalence	(buffer(6),configuration_status_register0)
equivalence	(buffer(7),configuration_status_register1)
equivalence	(buffer(8),maintenance_control_register)
integer*4	ram_count
integer*4	array_count
integer*4	starting_address
integer*4	error_syndrome
integer*4	error_bit
integer*4	error_array
integer*4	error_bank
integer*4	array_init_status_bits
integer*4	port_type_bits

```

0059 equivalence (ram_count,array_count,starting_address,error_syndrome,
0060 1_error_bit,error_array,array_init_status_bits,port_type_bits)
0061
0062 integer*4 compress4
0063 integer*4 compressc
0064 integer*4 i
0065 integer*4 j
0066 integer*4 lib$extzv
0067 integer*4 lib$locc
0068 integer*4 decode_ecc
0069 integer*4 adapter_tr
0070
0071 logical*1 diagnostic_mode
0072
0073 character*32 v1register2(0:1)
0074 data v1register2(0) /*MASTER INTERRUPT ENABLE*/
0075 data v1register2(1) /*PORT INTERFACE INTERRUPT ENABLE*/
0076
0077 character*30 v3register2(23:31)
0078 data v3register2(23) /*MARK INTERLOCK IN PROGRESS*/
0079 data v3register2(24) /*MARK TIMEOUT*/
0080 data v3register2(25) /*MARK REQUESTER*/
0081 data v3register2(26) /*OUTPUT BUFFER OVERFLOW*/
0082 data v3register2(27) /*INVALIDATION ACK NOT RECEIVED*/
0083 data v3register2(28) /*OUTPUT BUFFER PARITY ERROR*/
0084 data v3register2(29) /*INVALIDATE LOST ON BDI*/
0085 data v3register2(30) /*BDI PARITY FAULT ON OUTPUT*/
0086 data v3register2(31) /*BDI PARITY FAULT ON INPUT*/
0087
0088 character*23 v1register3(1)
0089 data v1register3(1) /*ERROR INTERRUPT ENABLE*/
0090
0091 character*25 v2register3(6:8)
0092 data v2register3(6) /*SELF INVALIDATE ENABLE*/
0093 data v2register3(7) /*INVALIDATION DISABLE*/
0094 data v2register3(8) /*INHIBIT ADMI ARBITRATION*/
0095
0096 character*25 v3register3(10:15)
0097 data v3register3(10) /*INTERLOCK GRANT ACCEPTED*/
0098 data v3register3(11) /*INTERLOCK FLIP-FLOP*/
0099 data v3register3(12) /*ARRAY INIT IN PROGRESS*/
0100
0101 c c c
0102 Cell 13 of this array unused
0103
0104 data v3register3(14) /*INVALIDATE DATA LOST*/
0105 data v3register3(15) /*INTERLOCK TIMEOUT*/
0106
0107 character*30 v4register3(21)
0108 data v4register3(21) /*NO C/A ON ADMI WHEN REQUESTED*/
0109
0110 character*23 v5register3(22:25,0:1)
0111 data v5register3(22,0) /*32-BIT OPERATION*/
0112 data v5register3(22,1) /*64-BIT OPERATION*/
0113 data v5register3(23,0) /*I/O SELECT*/
0114 data v5register3(23,1) /*ARRAY SELECT*/
0115 data v5register3(24,0) /*REQUESTER HAS NO CACHE*/

```

```

0173
0174
0175
0176
0177
0178
0179
0180
0181
0182
0183
0184
0185

```

PROG

```

0
1
2

```

ENTR

0-

VARI

```

2-
2-
2-
2-
2-
2-
2-
2-

```

ARRA

```

2-
2-
2-
2-

```

```

0116      data      v5register3(24,1)/*REQUESTER HAS CACHE*/
0117      data      v5register3(25,0)/*ADMI READ*/
0118      data      v5register3(25,1)/*ADMI WRITE*/
0119
0120      character*32 v6register3(28:31)
0121      data      v6register3(28) /*MULTIPLE ADMI GRANT*/
0122      data      v6register3(29) /*PORT TRANSMITTING DURING FAULT*/
0123      data      v6register3(30) /*ADMI MULTIPLE TRANSMITTER FAULT*/
0124      data      v6register3(31) /*ADMI COMMAND ABORT*/
0125
0126      character*14 v1register4(31:31)
0127      data      v1register4(31) /*CACHED FORCED*/
0128
0129      character*18 v1register5(28:31)
0130      data      v1register5(28) /*ERROR LOG REQUEST*/
0131      data      v1register5(29) /*HIGH ERROR RATE*/
0132      data      v1register5(30) /*CRD TAG*/
0133      data      v1register5(31) /*MAP PARITY ERROR*/
0134
0135      character*27 v1register6(0:1)
0136      data      v1register6(0) /*NONCONTIGUOUS ARRAY ERROR*/
0137      data      v1register6(1) /*4K CHIP ARRAY ERROR*/
0138
0139      character*28 v1register7(10:11)
0140      data      v1register7(10) /*MULTIPLE INTERLOCK ACCEPTED*/
0141      data      v1register7(11) /*INVALIDATION MAP PRESENT*/
0142
0143      character*27 array_init_status
0144      character*22 port_type
0145
0146
0147      call movc3 (xval(32),memory_registers,buffer)
0148
0149      diagnostic_mode = .false.
0150
0151      if (lib$extzv(4,3,port_interface_control_register) .ne. 0
0152      1 or
0153      1 lib$extzv(4,2,port_controller_status_register) .ne. 0
0154      1 or
0155      1 lib$extzv(13,1,port_controller_status_register) .ne. 0
0156      1 or
0157      1 lib$extzv(8,2,configuration_status_register1) .ne. 0
0158      1 or
0159      1 lib$extzv(8,6,maintenance_control_register) .ne. 0) then
0160
0161      diagnostic_mode = .true.
0162
0163      call linchk (lun,1)
0164
0165      write(lun,5) port_configuration_register
0166      format(/' ',t8,'PRTCFG',t24,z8.8)
0167      endif
0168
0169      call ma780_rega (lun,port_configuration_register)
0170
0171      call linchk (lun,1)
0172

```

5

```
0173 10 write(lun,10) port_interface_control_register
0174 format(' ',t8,'PTRCR',t24,z8.8)
0175
0176 if (.not. diagnostic_mode) then
0177
0178 call output (lun,port_interface_control_register,v1register2,0,0,1,'0')
0179
0180 call linchk (lun,1)
0181
0182 ram_count = lib$extzv(16,4,port_interface_control_register)
0183
0184 15 write(lun,15) ram_count
0185 format(' ',t40,'RAM COUNT ',i<compress4 (ram_count)>,'.')
0186
0187 call output (lun,port_interface_control_register,v3register2,23,23,31,
0188 1'0')
0189 endif
0190
0191 if (lib$extzv(4,3,port_interface_control_register) .ne. 0) then
0192
0193 call linchk (lun,1)
0194
0195 17 write(lun,17)
0196 format(' ',t40,'DIAGNOSTIC MODE')
0197 endif
0198
0199 call linchk (lun,1)
0200
0201 20 write(lun,20) port_controller_status_register
0202 format(' ',t8,'PCSR',t24,z8.8)
0203
0204 if (lib$extzv(13,1,port_controller_status_register) .ne. 0
0205 1.or.
0206 1 lib$extzv (4,2,port_controller_status_register) .ne. 0) then
0207
0208 call linchk (lun,1)
0209
0210 write(lun,17)
0211 endif
0212
0213 if (.not. diagnostic_mode) then
0214
0215 call output (lun,port_controller_status_register,v1register3,1,1,1,'0')
0216
0217 call output (lun,port_controller_status_register,v2register3,6,6,8,'0')
0218
0219 call output (lun,port_controller_status_register,v3register3,10,10,12,
0220 1'0')
0221
0222 call output (lun,port_controller_status_register,v3register3,10,14,15,
0223 1'0')
0224
0225 if (j1and(port_controller_status_register,'d0000000'x) .ne. 0) then
0226
0227 call output (lun,port_controller_status_register,v4register3,21,21,21,
0228 1'0')
0229
```

```
0230 call output (lun,port_controller_status_register,v5register3,22,22,25,  
0231 1,2)  
0232  
0233 I = LIB$EXTZV (26,2,port_controller_status_register)  
0234  
0235 call LINCHK (lun,1)  
0236 write (lun,25) I  
0237 25 format (' ',t40,'''ADMI'' PORT #',I<COMPRESS4 (I)>,'.')  
0238  
0239 call output (lun,port_controller_status_register,v6register3,28,28,31,  
0240 1,0)  
0241 endif  
0242 endif  
0243  
0244 call linchk (lun,1)  
0245  
0246 write(lun,30) port_invalidation_control_reg  
0247 30 format(' ',t8,'IVDTCR',t24,z8.8)  
0248  
0249 if (.not. diagnostic_mode) then  
0250  
0251 do 50,i = 0,15  
0252  
0253 if (lib$extzv(i,1,port_invalidation_control_reg) .eq. 1) then  
0254  
0255 call linchk (lun,1)  
0256  
0257 write(lun,40) i  
0258 40 format(' ',t40,'INVALIDATE CACHE DEVICE ID = ',i<compress4 (i)>,'.')  
0259 endif  
0260  
0261 50 continue  
0262  
0263 call linchk (lun,1)  
0264  
0265 array_count = lib$extzv(16,3,port_invalidation_control_reg)  
0266  
0267 if (array_count .eq. 0  
0268 1 .and.  
0269 1 lib$extzv(0,2,configuration_status_register0) .ne. 0) then  
0270  
0271 write(lun,60) 'INVALID ARRAY CONFIGURATION'  
0272 60 format(' ',t40,a)  
0273 else  
0274  
0275 write(lun,70) array_count + 1  
0276 70 format(' ',t40,i<compress4 (array_count + 1)>,  
0277 1 ' ARRAY BOARD(S) PRESENT')  
0278 endif  
0279  
0280 starting_address = lib$extzv(20,11,port_invalidation_control_reg)*256  
0281  
0282 call linchk (lun,1)  
0283  
0284 write(lun,80) starting_address  
0285 80 format(' ',t40,'MEMORY BASE ADDRESS = ',  
0286 1 i<compress4 (starting_address)>,'.K')
```

```
0002  
0003  
0004  
0005  
0006  
0007  
0008  
0009  
0010  
0011  
0012  
0013  
0014  
0015  
0016  
0017  
0018  
0019  
0020  
0021  
0022  
0023  
0024  
0025  
0026  
0027  
0028  
0029  
0030  
0031  
0032  
0033  
0034  
0035  
0036  
0037  
0038  
0039  
0040  
0041  
0042  
0043  
0044  
0045  
0046  
0047  
0048  
0049  
0050  
0051  
0052  
0053  
0054  
0055  
0056  
0057  
0058
```

```
0287  
0288      call output (lun,port_invalidation_control_reg,vlregister4,31,31,31,  
0289      1,'0')  
0290      endif  
0291  
0292      call linchk (lun,1)  
0293  
0294      write(lun,90) array_error_register  
0295  90      format(' ',t8,'AER',t24,z8.8)  
0296  
0297      if (.not. diagnostic_mode) then  
0298  
0299      if (lib$extzv (28,1,array_error_register) .eq. 1) then  
0300  
0301      error_syndrome = lib$extzv(0,8,array_error_register)  
0302  
0303      call linchk (lun,1)  
0304  
0305      write(lun,100) error_syndrome  
0306  100      format(' ',t40,'ERROR SYNDROME = ',z2.2)  
0307  
0308      error_bit = decode_ecc (error_syndrome,port_configuration_register)  
0309  
0310      call linchk (lun,1)  
0311  
0312      if (error_bit .eq. -1) then  
0313  
0314      write(lun,110) 'RDS ERROR'  
0315  110      format(' ',t40,a)  
0316      else  
0317  
0318      write(lun,120) 'CRD ERROR, CORRECTED BIT #',error_bit,'.'  
0319  120      format(' ',t40,a,i<compress4 (error_bit)>,.a)  
0320      endif  
0321  
0322      error_array = lib$extzv (24,4,array_error_register)  
0323  
0324      call linchk (lun,1)  
0325  
0326      write(lun,140) error_array  
0327  140      format(' ',t40,'ARRAY #',i<compress4 (error_array)>,'. IN ERROR')  
0328      endif  
0329  
0330      Error_bank = LIB$EXTZV(23,1,array_error_register)  
0331  
0332      call LINCHK (lun,1)  
0333      write (lun,145) error_bank  
0334  145      format(' ',t40,  
0335      1 'ARRAY BANK #',i<COMPRESS4 (error_bank)>,'. IN ERROR')  
0336  
0337      call output (lun,array_error_register,vlregister5,28,28,31,'0')  
0338      endif  
0339  
0340      call linchk (lun,1)  
0341  
0342      write(lun,170) configuration_status_register0  
0343  170      format(' ',t8,'CSR0',t24,z8.8)
```

```
0059  
0060  
0061  
0062  
0063  
0064  
0065  
0066  
0067  
0068  
0069  
0070  
0071  
0072  
0073  
0074  
0075  
0076  
0077  
0078  
0079  
0080  
0081  
0082  
0083  
0084  
0085  
0086  
0087  
0088  
0089  
0090  
0091  
0092  
0093  
0094  
0095  
0096  
0097  
0098  
0099  
0100  
0101  
0102  
0103  
0104  
0105  
0106  
0107  
0108  
0109  
0110  
0111  
0112  
0113  
0114  
0115
```

```
0344
0345     if (.not. diagnostic_mode) then
0346
0347     call output (lun,configuration_status_register0,vregister6,0,0,1,'0')
0348
0349     array_init_status_bits = lib$extzv(2,2,configuration_status_register0)
0350
0351     if (array_init_status_bits .eq. 0) then
0352
0353     array_init_status = 'INITIALIZATION IN PROGRESS*'
0354
0355     else if (array_init_status_bits .eq. 2) then
0356
0357     array_init_status = 'MEMORY CONTAINS VALID DATA*'
0358
0359     else if (array_init_status_bits .eq. 3) then
0360
0361     array_init_status = 'INITIALIZATION COMPLETE*'
0362     endif
0363
0364     call linchk (lun,1)
0365
0366     write(lun,180) array_init_status(:(lib$locc('* ',array_init_status)-1))
180     format(' ',t40,a)
0367
0368     do 200,i = 4,7
0369
0370
0371     if (lib$extzv(i,1,configuration_status_register0) .eq. 1) then
0372
0373     call linchk (lun,1)
0374
0375     write(lun,190) 'PORT #',i - 4,'. POWERED DOWN'
190     format(' ',t40,a,i<compress4 (i - 4)>,a)
0376
0377     endif
0378
0379     200 continue
0380
0381     do 220,i = 8,11
0382
0383     if (lib$extzv(i,1,configuration_status_register0) .eq. 1) then
0384
0385     call linchk (lun,1)
0386
0387     write(lun,210) 'ERROR INTERRUPT FROM PORT #',i - 8,'.'
210     format(' ',t40,a,i<compress4 (i - 8)>,a)
0388
0389     endif
0390
0391     220 continue
0392
0393     do 240,i = 12,15
0394
0395     if (lib$extzv(i,1,configuration_status_register0) .eq. 1) then
0396
0397     call linchk (lun,1)
0398
0399     write(lun,230) 'PORT #',i - 12,'. OFFLINE'
230     format(' ',t40,a,i<compress4 (i - 12)>,a)
0400
```

```
0116
0117
0118
0119
0120
0121
0122
0123
0124
0125
0126
0127
0128
0129
0130
0131
0132
0133
0134
0135
0136
0137
0138
0139
0140
0141
0142
0143
0144
0145
0146
0147
0148
0149
0150
0151
0152
0153
0154
0155
0156
0157
0158
0159
0160
0161
0162
0163
0164
0165
0166
0167
0168
0169
0170
0171
0172
```

```
0401      endif
0402
0403 240      continue
0404      endif
0405
0406      call linchk (lun,1)
0407
0408 250      write(lun,250) configuration_status_register1
0409      format(' ',t8,'(SR1',t24,z8.8)
0410
0411      if (.not. diagnostic_mode) then
0412
0413      do 270,i = 0,6,2
0414
0415      port_type_bits = lib$extzv(i,2,configuration_status_register1)
0416
0417      if (port_type_bits .eq. 0) then
0418
0419      port_type = ' . NOT PRESENT*'
0420
0421      else if (port_type_bits .eq. 2) then
0422
0423      port_type = ' . CONNECTED TO AN SBI*'
0424      endif
0425
0426      if (port_type_bits .ne. 1
0427      1 .or.
0428      1 port_type_bits .ne. 3) then
0429
0430      call linchk (lun,1)
0431
0432 260      write(lun,260) i/2,port_type
0433      format(' ',t40,'PORT #',i<compress4 (i/2)>,<compressc (port_type)>)
0434      endif
0435
0436 270      continue
0437
0438      call output (lun,configuration_status_register1,vlregister7,10,10,11,
0439      1 '0')
0440
0441      do 290,i = 12,15
0442
0443      if (lib$extzv(i,1,configuration_status_register1) .eq. 1) then
0444
0445      call linchk (lun,1)
0446
0447 280      write(lun,280) 'PORT #',i - 12,' . INVALIDATION ACK RECEIVED'
0448      format(' ',t40,<compress4 (i - 12)>,<compressc (i - 12)>,<compressc (i - 12)>)
0449      endif
0450
0451 290      continue
0452      endif
0453
0454      if (lib$extzv(8,2,configuration_status_register1) .ne. 0) then
0455
0456      call linchk (lun,1)
0457
```

```
0173
0174
0175
0176
0177
0178
0179
0180
0181
0182
0183
0184
0185
0186
0187
0188
0189
0190
0191
0192
0193
0194
0195
0196
0197
0198
0199
0200
0201
0202
0203
```

```
0458      write(lun,17)
0459      endif
0460
0461      call linchk (lun,1)
0462
0463      write(lun,295) maintenance_control_register
0464 295      format(' ',t8,'MAT',t24,z8.8)
0465
0466      if (lib$extzv(8,6,maintenance_control_register) .ne. 0) then
0467
0468      call linchk (lun,1)
0469
0470      write(lun,17)
0471      endif
0472
0473      return
0474      end
```

## PROGRAM SECTIONS

Name	Bytes	Attributes
0 \$CODE	2631	PIC CON REL LCL SHR EXE RD NOWRT LONG
1 \$PDATA	919	PIC CON REL LCL SHR NOEXE RD NOWRT LONG
2 \$LOCAL	3188	PIC CON REL LCL NOSHR NOEXE RD WRT LONG
Total Space Allocated	6738	

## ENTRY POINTS

Address	Type	Name
0-00000000		MA780

## VARIABLES

Address	Type	Name	Address	Type	Name
2-0000071C	I*4	ADAPTER_TR	2-00000000	I*4	ARRAY_COUNT
2-00000014	I*4	ARRAY_ERROR_REGISTER	2-000006DD	CHAR	ARRAY_INIT_STATUS
2-00000000	I*4	ARRAY_INIT_STATUS_BITS	2-00000018	I*4	CONFIGURATION_STATUS_REGISTER0
2-0000001C	I*4	CONFIGURATION_STATUS_REGISTER1	2-000006DC	I*4	DIAGNOSTIC_MODE
2-00000000	I*4	ERROR_ARRAY	2-00000710	I*4	ERROR_BANK
2-00000000	I*4	ERROR_BIT	2-00000000	I*4	ERROR_SYNDROME
2-00000714	I*4	I	2-00000718	I*4	J
AP-000000042	L*1	LUN	2-00000020	I*4	MAINTENANCE_CONTROL_REGISTER
AP-000000082	I*4	MEMORY_REGISTERS	2-00000004	I*4	PORT_CONFIGURATION_REGISTER
2-0000000C	I*4	PORT_CONTROLLER_STATUS_REGISTER	2-00000008	I*4	PORT_INTERFACE_CONTROL_REGISTER
2-00000010	I*4	PORT_INVALIDATION_CONTROL_REG	2-000006F8	CHAR	PORT_TYPE
2-00000000	I*4	PORT_TYPE_BITS	2-00000000	I*4	RAM_COUNT
2-00000000	I*4	STARTING_ADDRESS			

## ARRAYS

Address	Type	Name	Bytes	Dimensions
2-00000004	I*4	BUFFER	32	(8)
2-00000024	CHAR	V1REGISTER2	64	(0:1)
2-00000172	CHAR	V1REGISTER3	23	(1)
2-00000618	CHAR	V1REGISTER4	14	(31:31)
2-00000626	CHAR	V1REGISTER5	72	(28:31)
2-0000066E	CHAR	V1REGISTER6	54	(0:1)
2-000006A4	CHAR	V1REGISTER7	56	(10:11)
2-00000189	CHAR	V2REGISTER3	75	(6:8)
2-00000064	CHAR	V3REGISTER2	270	(23:31)
2-000001D4	CHAR	V3REGISTER3	150	(10:15)
2-0000026A	CHAR	V4REGISTER3	630	(21)
2-000004E0	CHAR	V5REGISTER3	184	(22:25 0:1)
2-00000598	CHAR	V6REGISTER3	128	(28:31)

## LABELS

Address	Label	Address	Label	Address	Label	Address	Label	Address	Label	Address	Label
1-000000F4	5'	1-00000109	10'	1-0000011B	15'	1-00000136	17'	1-0000014D	20'	1-0000015E	25'
1-0000017C	30'	1-0000018F	40'	**	50	1-000001BD	60'	1-000001C4	70'	1-000001EA	80'
1-00000212	90'	1-00000222	100'	1-0000023E	110'	1-00000245	120'	1-00000253	140'	1-00000274	145'
1-0000029A	170'	1-000002AB	180'	1-000002B2	190'	**	200	1-000002C0	210'	**	220
1-000002CE	230'	**	240	1-000002DC	250'	1-000002ED	260'	**	270	1-00000307	280'
**	290	1-00000315	295'								

## FUNCTIONS AND SUBROUTINES REFERENCED

Type	Name	Type	Name	Type	Name	Type	Name	Type	Name
I*4	COMPRESS4 MA780_REGA	I*4	COMPRESSC MOVC3	I*4	DECODE_ECC OUTPUT	I*4	LIB\$EXTZV	I*4	LIB\$LOCC
									LINCHK

0001

<sup>F 4</sup>  
16-Sep-1984 00:07:33  
5-Sep-1984 14:01:18

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:[ERF.SRC]MEMORY.S.FOR;1

Page 24

0001

This routine displays the error log packet for the ms780c memory controller. The format of the packet is as follows.

```

+-----+
| memory register A |
+-----+
| memory register B |
+-----+
| memory register C |
+-----+

```

Implicit	none
----------	------

byte lun

```
integer*4      memory_registers
integer*4      adapter_tr
integer*4      buffer(3)
integer*4      memory_register_a
integer*4      memory_register_b
integer*4      memory_register_c
```

```
equivalence (buffer(1),memory_register_a)
equivalence (buffer(2),memory_register_b)
equivalence (buffer(3),memory_register_c)
```

```
character*27      memory_init_status(0:3)
data              memory_init_status(0)      /*INITIALIZATION IN PROGRESS*/
data              memory_init_status(1)      /*MEMORY CONTAINS VALID DATA*/
data              memory_init_status(2)      /*INVALID STATE*/
data              memory_init_status(3)      /*INITIALIZATION COMPLETE*/
```

```
character=27      v2memory_registerb(14:14)
data              v2memory_registerb(14)  /*START ADDRESS WRITE ENABLE*/
```

```
character*18      vlmemory_registerc(28:30)
data              vlmemory_registerc(28)  /*ERROR LOG REQUEST*/
data              vlmemory_registerc(29)  /*HIGH ERROR RATE*/
data              vlmemory_registerc(30)  /*INHIBIT CRD TAG*/
```

```
integer*4      libextzv
integer*4      l
integer*4      decode_ecc
integer*4      compress4
integer*4      compressc
integer*4      init_status
integer*4      starting_address
integer*4      error_syndrome
integer*4      error_bit
integer*4      error_bank_address
integer*4      error_array
```

```
0059      logical*1      diagnostic_mode
0060      Logical*1      four_k
0061      Logical*1      sixteen_k
0062
0063
0064
0065      call movc3 (%val(12),memory_registers,buffer)
0066
0067      diagnostic_mode = .false.
0068
0069      if (lib$extzv (8,2,memory_register_b) .ne. 0) diagnostic_mode = .true.
0070
0071      if (.not. diagnostic_mode) then
0072
0073      call ms780c_rega (lun,memory_register_a)
0074      else
0075
0076      call linchk (lun,1)
0077
0078      5      write(lun,5) memory_register_a
0079      format('i',t8,'CSRA',t24,z8.8)
0080      endif
0081
0082      Four_k = .false.
0083      Sixteen_k = .false.
0084
0085      If (LIB$EXTZV(3,2,memory_register_a) .EQ. 1) four_k = .true.
0086      If (LIB$EXTZV(3,2,memory_register_a) .EQ. 2) sixteen_k = .true.
0087
0088      call linchk (lun,1)
0089
0090      10      write(lun,10) 'CSRB',memory_register_b
0091      format('i',t8,a,t24,z8.8)
0092
0093      if (diagnostic_mode) then
0094
0095      call linchk (lun,1)
0096
0097      12      write(lun,12) 'DIAGNOSTIC MODE'
0098      format('i',t40,a)
0099      endif
0100
0101      if (.not. diagnostic_mode) then
0102
0103      init_status = lib$extzv(12,2,memory_register_b)
0104
0105      call linchk (lun,1)
0106
0107      30      write(lun,30) memory_init_status(init_status)
0108      format('i',t40,a,<compressc (memory_init_status(init_status))>)
0109
0110      call output (lun,memory_register_b,v2memory_registerb,14,14,14,'0')
0111
0112      starting_address = lib$extzv(15,13,memory_register_b)*64
0113
0114      call linchk (lun,1)
0115
```

```
0059
0060
0061
0062
0063
0064
0065
0066
0067
0068
0069
0070
0071
0072
0073
0074
0075
0076
0077
0078
0079
0080
0081
0082
0083
0084
0085
0086
0087
0088
0089
0090
0091
0092
0093
0094
0095
0096
0097
0098
0099
0100
0101
0102
0103
0104
0105
0106
0107
0108
0109
0110
0111
0112
0113
0114
0115
```

```
0116 write(lun,35) starting_address
0117 35 format(' ',t40,'MEMORY BASE ADDRESS = ',
0118 1 i<compress4 (starting_address)>,>,'.K')
0119
0120 call linchk (lun,2)
0121
0122 write(lun,40) (lib$extzv(i,2,memory_register_b),i = 28,30,2)
0123 40 format(' ',t40,'FILE INPUT POINTER ',
0124 1 i<compress4 (lib$extzv(i,2,memory_register_b))>,>,'.',/,
0125 1 t40,'FILE OUTPUT POINTER ',
0126 1 i<compress4 (lib$extzv(i,2,memory_register_b))>,>,'.')
0127 endif
0128
0129 call linchk (lun,1)
0130
0131 write(lun,45) 'CSRC',memory_register_c
0132 45 format(' ',t8,a,t24,z8.8)
0133
0134 if (.not. diagnostic_mode) then
0135
0136 if (lib$extzv(28,1,memory_register_c) .eq. 1) then
0137
0138 error_syndrome = lib$extzv(0,8,memory_register_c)
0139
0140 call linchk (lun,1)
0141
0142 write(lun,15) error syndrome
0143 15 format(' ',t40,'ERROR SYNDROME = ',z2.2)
0144
0145 error_bit = decode_ecc (error_syndrome,memory_register_a)
0146
0147 call linchk (lun,1)
0148
0149 if (error_bit .eq. -1) then
0150
0151 write(lun,20) 'RDS ERROR'
0152 20 format(' ',t40,a)
0153 else
0154
0155 write(lun,25) 'CRD ERROR, CORRECTED BIT #',error_bit,'.'
0156 25 format(' ',t40,a,i<compress4 (error_bit)>,>a)
0157 endif
0158
0159 if (four_k) then
0160 Error_bank_address = LIB$EXTZV(21,1,memory_register_c)
0161
0162 Else if (sixteen_k) then
0163 Error_bank_address = LIB$EXTZV(23,1,memory_register_c)
0164
0165 Endif
0166
0167 call linchk (lun,1)
0168
0169 write(lun,47) error bank address
0170 47 format(' ',t40,'ARRAY BANK #',
0171 1 i<compress4 (error_bank_address)>,>,'. IN ERROR')
0172
```

```
0116
0117
0118
0119
0120
0121
0122
0123
0124
0125
0126
0127
0128
0129
0130
0131
0132
0133
0134
0135
0136
0137
0138
0139
0140
0141
0142
0143
0144
0145
0146
0147
0148
0149
0150
0151
0152
0153
0154
0155
0156
0157
0158
0159
0160
0161
0162
0163
0164
0165
0166
0167
0168
0169
0170
0171
0172
```

```
0173      error_array = lib$extzv(24,4,memory_register_c)
0174      call linchk (lun,1)
0175
0176      write(lun,50) error_array
0177      format(' ',t40,'ARRAY #',i<compress4 (error_array)>,'. IN ERROR')
0178      50
0179      endif
0180
0181      call output (lun,memory_register_c,vmemory_registerc,28,28,30,'0')
0182      endif
0183
0184      return
0185      end
```

PROGRAM SECTIONS

Name	Bytes	Attributes							
0 \$CODE	1100	PIC	CON	REL	LCL	SHR	EXE	RD	NOWRT LONG
1 \$PDATA	411	PIC	CON	REL	LCL	SHR	NOEXE	RD	NOWRT LONG
2 \$LOCAL	716	PIC	CON	REL	LCL	NOSHR	NOEXE	RD	WRT LONG
Total Space Allocated		2227							

ENTRY POINTS

Address	Type	Name
0-00000000		MS780C

VARIABLES

Address	Type	Name	Address	Type	Name
2-000000CC	I*4	ADAPTER_TR	2-000000C9	L*1	DIAGNOSTIC_MODE
2-000000E8	I*4	ERROR_ARRAY	2-000000E4	I*4	ERROR_BANK_ADDRESS
2-000000E0	I*4	ERROR_BIT	2-000000DC	I*4	ERROR_SYNDROME
2-000000CA	L*1	FOUR_K	2-000000D0	I*4	I
2-000000D4	I*4	INIT_STATUS	AP-00000004	L*1	LUN
AP-00000008	I*4	MEMORY_REGISTERS	2-00000000	I*4	MEMORY_REGISTER_A
2-00000004	I*4	MEMORY_REGISTER_B	2-00000008	I*4	MEMORY_REGISTER_C
2-000000CB	L*1	SIXTEEN_K	2-000000D8	I*4	STARTING_ADDRESS

ARRAYS

Address	Type	Name	Bytes	Dimensions
2-00000000	I*4	BUFFER	12	(3)
2-0000000C	CHAR	MEMORY_INIT_STATUS	108	(0:3)
2-00000093	CHAR	V1MEMORY_REGISTERC	54	(28:30)
2-00000078	CHAR	V2MEMORY_REGISTERB	27	(14:14)

MS751

0173  
0174  
0175  
0176  
0177  
0178  
0179  
0180  
0181  
0182  
0183  
0184  
0185  
0186  
0187  
0188  
0189  
0190  
0191  
0192  
0193  
0194  
0195  
0196  
0197  
0198  
0199  
0200  
0201  
0202  
0203  
0204  
0205  
0206  
0207  
0208  
0209  
0210  
0211  
0212  
0213  
0214  
0215  
0216  
0217  
0218  
0219  
0220  
0221  
0222  
0223  
0224  
0225  
0226  
0227  
0228  
0229

LABELS

Address	Label	Address	Label	Address	Label	Address	Label	Address	Label	Address	Label
1-00000079	5'	1-0000008A	10'	1-00000096	12'	1-00000123	15'	1-0000013F	20'	1-00000146	25'
1-0000009D	30'	1-000000A9	35'	1-000000D1	40'	1-00000117	45'	1-00000154	47'	1-0000017A	50'

FUNCTIONS AND SUBROUTINES REFERENCED

Type	Name	Type	Name	Type	Name	Type	Name	Type	Name
I*4	COMPRESS4 MS780C_REGA	I*4	COMPRESSC OUTPUT	I*4	DECODE_ECC	I*4	LIBSEXTZV		LINCHK
									MOV3

MS751  
0230  
0231  
0232  
0233  
0234  
0235  
0236  
0237  
0238  
0239  
0240  
0241  
0242  
0243  
0244  
0245  
0246  
0247  
0248  
0249  
0250  
0251  
0252  
0253  
0254  
0255  
0256  
0257  
0258  
0259  
0260  
0261  
0262  
0263  
0264  
0265  
0266  
0267  
0268  
0269  
0270  
0271

0001

1<sup>4</sup>  
18-Sep-1984 00:07:33  
9-Sep-1984 14:01:18

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:LERF.SRCJMEMORYS.FOR;1

Page 30

MS751

PROG

0  
1  
2

ENTR

0-1

VARI

2-1  
2-1  
2-1  
2-1  
2-1  
2-1  
2-1  
2-1  
2-1  
2-1

ARRA

2-1  
2-1  
2-1  
2-1  
2-1

LABEL

1-1  
1-1  
1-1

Subroutine MS780E (lun,memory\_registers)

This routine displays the error log packet for the ms780e  
memory controller. The format of the packet is as follows.

```

+-----+
| memory register A |
+-----+
| memory register B |
+-----+
| memory register C |
+-----+
| memory register D |
+-----+

```

Implicit none

byte lun

integer\*4 memory\_registers  
integer\*4 buffer(4)  
integer\*4 memory\_register\_a  
integer\*4 memory\_register\_b  
integer\*4 memory\_register('c'x:'d'x)

equivalence (buffer(1),memory\_register\_a)  
equivalence (buffer(2),memory\_register\_b)  
equivalence (buffer(3),memory\_register)

logical\*1 diagnostic\_mode

integer\*4 decode\_ecc  
integer\*4 compress4  
integer\*4 compressc  
integer\*4 lib\$extzv  
integer\*4 i

character\*27 memory\_init\_status(0:3)  
data memory\_init\_status(0) /\*INITIALIZATION IN PROGRESS\*/  
data memory\_init\_status(1) /\*MEMORY CONTAINS VALID DATA\*/  
data memory\_init\_status(2) /\*INVALID STATE\*/  
data memory\_init\_status(3) /\*INITIALIZATION COMPLETE\*/

character\*33 v1memory\_registerb(7:7)  
data v1memory\_registerb(7)  
1 /\*SBI INTERFACE WRITE PARITY ERROR\*/

character\*27 v2memory\_registerb(14:14)  
data v2memory\_registerb(14) /\*START ADDRESS WRITE ENABLE\*/

character\*29 v1memory\_register(7:7)  
data v1memory\_register(7)  
1 /\*MICRO-SEQUENCER PARITY ERROR\*/

character\*18 v2memory\_register(28:30)

```

0059      data      v2memory_register(28)  /*'ERROR LOG REQUEST'*/
0060      data      v2memory_register(29)  /*'HIGH ERROR RATE'*/
0061      data      v2memory_register(30)  /*'INHIBIT CRD TAG'*/
0062
0063      integer*4   init_status
0064      integer*4   starting_address
0065      integer*4   error_syndrome
0066      integer*4   error_bit
0067      integer*4   error_bank_address
0068      integer*4   error_array
0069      integer*4   adapter_tr
0070
0071
0072      call movc3 (%val(16),memory_registers,buffer)
0073
0074      diagnostic_mode = .false.
0075
0076      if (
0077      1 lib$extzv(7,3,memory_register_b) .ne. 0
0078      1 .or.
0079      1 lib$extzv(11,1,memory_register_b) .eq. 1
0080      1 .or.
0081      1 lib$extzv(31,1,memory_register('c'x)) .eq. 1
0082      1 .or.
0083      1 lib$extzv(31,1,memory_register('d'x)) .eq. 1
0084      1 ) then
0085
0086      diagnostic_mode = .true.
0087      endif
0088
0089      if (.not. diagnostic_mode) then
0090
0091      call ms780e_rega (lun,memory_register_a)
0092      else
0093
0094      call linchk (lun,1)
0095
0096      write(lun,5) memory_register_a
0097      5 format(' ',t8,'CSRA',t24,z8.8)
0098      endif
0099
0100      call linchk (lun,1)
0101
0102      write(lun,10) 'CSRB',memory_register_b
0103      10 format(' ',t8,a,t24,z8.8)
0104
0105      if (diagnostic_mode) then
0106
0107      call linchk (lun,1)
0108
0109      write(lun,12) 'DIAGNOSTIC MODE'
0110      12 format(' ',t40,a)
0111      endif
0112
0113      if (.not. diagnostic_mode) then
0114
0115      init_status = lib$extzv(12,2,memory_register_b)

```

```
0116      call linchk (lun,1)
0117
0118      write(lun,15) memory_init_status(init_status)
0119      format(' ',t40,a<compressc (memory_init_status(init_status))>>)
0120 15      call output (lun,memory_register_b,v1memory_registerb,7,7,7,'0')
0121
0122      call output (lun,memory_register_b,v2memory_registerb,14,14,14,'0')
0123
0124      starting_address = lib$extzv(19,9,memory_register_b)
0125
0126      call linchk (lun,1)
0127
0128      write(lun,20) starting_address
0129      format(' ',t40,'MEMORY BASE ADDRESS = ',
0130 20      1 i<compress4 (starting_address)>,'.M')
0131      endif
0132
0133      do 55,i = 'c'x,'d'x
0134
0135      call linchk (lun,1)
0136
0137      if (i .eq. 'c'x) then
0138
0139      write(lun,25) 'C',memory_register(i)
0140      format(' ',t8,'CSR',a,t24,z8.8)
0141 25      else if (i .eq. 'd'x) then
0142
0143      write(lun,25) 'D',memory_register(i)
0144      endif
0145
0146      if (.not. diagnostic_mode) then
0147
0148      if (lib$extzv(28,1,memory_register(i)) .eq. 1) then
0149
0150      error_syndrome = lib$extzv(0,7,memory_register(i))
0151
0152      call linchk (lun,1)
0153
0154      write(lun,30) error_syndrome
0155      format(' ',t40,'ERROR SYNDROME = ',z2.2)
0156 30
0157      error_bit = decode_ecc (error_syndrome,memory_register_a)
0158
0159      call linchk (lun,1)
0160
0161      if (error_bit .eq. -1) then
0162
0163      write(lun,35) 'RDS ERROR'
0164      format(' ',t40,a)
0165 35      else
0166
0167      write(lun,40) 'CRD ERROR, CORRECTED BIT #',error_bit,'.'
0168      format(' ',t40,a,i<compress4 (error_bit)>,a)
0169 40      endif
0170
0171
0172
```

```
0002
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037
0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050
0051
0052
0053
0054
0055
0056
0057
0058
```

```
0173  
0174      call output (lun,memory_register(i),v1memory_register,7,7,7,'0')  
0175  
0176      error_bank_address = lib$extzv(22,2,memory_register(i))  
0177  
0178      call linchk (lun,1)  
0179  
0180      write(lun,45) error_bank_address  
45      format(' ',t40,'ARRAY BANK #',  
0181      1 i<compress4 (error_bank_address)>,'. IN ERROR')  
0182  
0183      error_array = lib$extzv(24,3,memory_register(i))  
0184  
0185      if (i .EQ. 'd'x) then  
0186      Error_array = error_array + 8  
0187  
0188      Endif  
0189  
0190      call linchk (lun,1)  
0191  
0192      write(lun,50) error_array  
50      format(' ',t40,'ARRAY #',i<compress4 (error_array)>,'. IN ERROR')  
0193      endif  
0194  
0195      call output (lun,memory_register(i),v2memory_register,28,28,30,'0')  
0196      endif  
0197  
0198  
0199      55      continue  
0200  
0201      return  
0202      end  
0203
```

```
0059  
0060  
0061  
0062  
0063  
0064  
0065  
0066  
0067  
0068  
0069  
0070  
0071  
0072  
0073  
0074  
0075  
0076  
0077  
0078  
0079  
0080  
0081  
0082  
0083  
0084  
0085  
0086  
0087  
0088  
0089  
0090  
0091  
0092  
0093  
0094  
0095  
0096  
0097  
0098  
0099  
0100  
0101  
0102  
0103  
0104  
0105  
0106  
0107  
0108  
0109  
0110  
0111  
0112  
0113  
0114  
0115
```

PROGRAM SECTIONS

Name	Bytes	Attributes							
0 \$CODE	1098	PIC	CON	REL	LCL	SHR	EXE	RD	NOWRT LONG
1 \$PDATA	344	PIC	CON	REL	LCL	SHR	NOEXE	RD	NOWRT LONG
2 \$LOCAL	888	PIC	CON	REL	LCL	NOSHR	NOEXE	RD	WRT LONG
Total Space Allocated		2330							

ENTRY POINTS

Address	Type	Name
0-00000000		MS780E

VARIABLES

Address	Type	Name	Address	Type	Name
2-00000128	I*4	ADAPTER_TR	2-00000108	L*1	DIAGNOSTIC_MODE
2-00000124	I*4	ERROR_ARRAY	2-00000120	I*4	ERROR_BANK_ADDRESS
2-0000011C	I*4	ERROR_BIT	2-00000118	I*4	ERROR_SYNDROME
2-0000010C	I*4	I	2-00000110	I*4	INIT STATUS
AP-00000004	L*1	LUN	AP-00000008	I*4	MEMORY_REGISTERS
2-00000000	I*4	MEMORY_REGISTER_A	2-00000004	I*4	MEMORY_REGISTER_B
2-00000114	I*4	STARTING_ADDRESS			

ARRAYS

Address	Type	Name	Bytes	Dimensions
2-00000000	I*4	BUFFER	16	(4)
2-00000010	CHAR	MEMORY_INIT_STATUS	108	(0:3)
2-00000008	I*4	MEMORY_REGISTER	8	(12:13)
2-00000088	CHAR	V1MEMORY_REGISTER	29	(7:7)
2-0000007C	CHAR	V1MEMORY_REGISTERB	33	(7:7)
2-000000D5	CHAR	V2MEMORY_REGISTER	54	(28:30)
2-0000009D	CHAR	V2MEMORY_REGISTERB	27	(14:14)

LABELS

Address	Label	Address	Label	Address	Label	Address	Label	Address	Label
1-00000077	5'	1-00000088	10'	1-00000094	12'	1-0000009B	15'	1-000000A7	20'
1-000000E0	30'	1-000000FC	35'	1-00000103	40'	1-00000111	45'	1-00000137	50'
								**	55'

0116  
0117  
0118  
0119  
0120  
0121  
0122  
0123  
0124  
0125  
0126  
0127  
0128  
0129  
0130  
0131  
0132  
0133  
0134  
0135  
0136  
0137  
0138  
0139  
0140  
0141  
0142  
0143  
0144  
0145  
0146  
0147  
0148  
0149  
0150  
0151  
0152  
0153  
0154  
0155  
0156  
0157  
0158  
0159  
0160  
0161  
0162  
0163  
0164  
0165  
0166  
0167  
0168  
0169  
0170  
0171  
0172

FUNCTIONS AND SUBROUTINES REFERENCED

Type	Name	Type	Name	Type	Name	Type	Name	Type	Name
I*4	COMPRESS4 MS780E_REGA	I*4	COMPRESSC OUTPUT	I*4	DECODE_ECC	I*4	LIB\$EXTZV		LINCHK MOV3

0173  
0174  
0175  
0176  
0177  
0178  
0179  
0180  
0181  
0182  
0183  
0184  
0185  
0186  
0187

PROG

0  
1  
2

ENTR

0-

VARI

2-  
2-  
2-  
AP-  
2-  
AP-

ARRA

2-  
2-  
2-  
2-

0001

F 5  
16-Sep-1984 00:07:33  
5-Sep-1984 14:01:18

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:[ERF.SRC]MEMORYS.FOR;1 Page 37

MS73

LABE

1:  
1:

FUNC

Ty

1

Subroutine MS750 (lun,memory\_registers)

Functional description:

This module displays ms750 memory error packets. The format is as follows.

```

+-----+
| memory register 0 |
+-----+
| memory register 1 |
+-----+
| memory register 2 |
+-----+

```

Implicit none

byte lun

integer\*4 memory\_registers

integer\*4 slot\_index

integer\*4 buffer(3)

integer\*4 memory\_register\_0

integer\*4 memory\_register\_1

integer\*4 memory\_register\_2

equivalence (buffer(1),memory\_register\_0)

equivalence (buffer(2),memory\_register\_1)

equivalence (buffer(3),memory\_register\_2)

character\*35 vmemory\_register0(29:31)

data vmemory\_register0(29) /'CORRECTED ERROR FLAG\*'/

data vmemory\_register0(30)

1 /'UNCORRECTED ERROR INFORMATION LOST\*'/

data vmemory\_register0(31) /'UNCORRECTED ERROR FLAG\*'/

character\*34 vmemory\_register1(28:28)

data vmemory\_register1(28)

1 /'ENABLE REPORTING CORRECTED ERRORS\*'/

character\*23 vmemory\_register2(16:16)

data vmemory\_register2(16) /'BATTERY BACKUP FAILURE\*'/

integer\*4 compress4

integer\*4 lib\$extzv

integer\*4 i

integer\*4 decode\_ecc

integer\*4 error\_bit

integer\*4 error\_array

integer\*4 error\_bank

integer\*4 arrays\_present

integer\*4 start\_address

equivalence (error\_bit,error\_array,arrays\_present,

```
0059 1 start_address)
0060
0061 integer*4      array_code
0062
0063 logical*1      diagnostic_mode
0064 logical*1      l0011
0065 logical*1      l0016
0066
0067 call movc3 (%val(12),memory_registers,buffer)
0068
0069 diagnostic_mode = .false.
0070
0071 if (lib$extzv(25,3,memory_register_1) .ne. 0) diagnostic_mode = .true.
0072
0073 call linchk (lun,2)
0074
0075
0076 10 write(lun,10) memory_register_0
0077    format(/' ',t8,'CSRO',t24,z8.8)
0078
0079    if (.not. diagnostic_mode) then
0080
0081    call linchk (lun,1)
0082
0083 15 write(lun,15) lib$extzv(0,7,memory_register_0)
0084    format(' ',t40,'ERROR SYNDROME = ',z2.2)
0085
0086    if (lib$extzv(29,1,memory_register_0) .eq. 1) then
0087
0088    error_bit = decode_ecc (lib$extzv(0,7,memory_register_0))
0089
0090    call linchk (lun,1)
0091
0092    if (error_bit .eq. -1) then
0093
0094    write(lun,20) "'ECC" CODE, UNCORRECTED ERROR'
0095    else
0096
0097 20 write(lun,20) 'CORRECTED ERROR, BIT #',error_bit,'.'
0098    format(' ',t40,a,:i<compress4 (error_bit)>,:a)
0099    endif
0100    endif
0101
0102    if (lib$extzv(30,1,memory_register_0) .eq. 0) then
0103
0104    error_array = lib$extzv(9,15,memory_register_0)
0105
0106    l0011 = .false.
0107
0108    l0016 = .false.
0109
0110    if (lib$extzv(24,1,memory_register_2) .eq. 1) then
0111
0112    l0016 = .true.
0113    else
0114
0115    l0011 = .true.
```

```
0003
0004
0005
0006
0007
0008
0009
0010
0011
0012
0013
0014
0015
0016
0017
0018
0019
0020
0021
0022
0023
0024
0025
0026
0027
0028
0029
0030
0031
0032
0033
0034
0035
0036
0037
0038
0039
0040
0041
0042
0043
0044
0045
0046
0047
0048
0049
0050
0051
0052
0053
0054
0055
0056
0057
0058
0059
```

```
0116      endif
0117      do 25,i = 0,15,2
0118      array_code = lib$extzv(i,2,memory_register_2)
0119      if (l0016) then
0120      if (array_code .eq. 3) then
0121      error_array = error_array - 512
0122      If (LIB$EXTZV(17,1,memory_register_0) .EQ. 0) then
0123      Error_bank = 0
0124      Else
0125      Error_bank = 1
0126      Endif
0127      else if (array_code .eq. 2) then
0128      error_array = error_array - 2048
0129      Error_bank = LIB$EXTZV(19,2,memory_register_0)
0130      endif
0131      else if (l0011) then
0132      if (array_code .eq. 1) then
0133      error_array = error_array - 256
0134      Error_bank = 0
0135      else if (array_code .eq. 3) then
0136      error_array = error_array - 512
0137      If (LIB$EXTZV(17,1,memory_register_0) .EQ. 0) then
0138      Error_bank = 0
0139      Else
0140      Error_bank = 1
0141      Endif
0142      endif
0143      endif
0144      if (error_array .le. 0) then
0145      error_array = i/2
0146      goto 26
0147      endif
0148      25 continue
```

25

0060  
0061  
0062  
0063  
0064  
0065  
0066  
0067  
0068  
0069  
0070  
0071  
0072  
0073  
0074  
0075  
0076  
0077  
0078

PROG

0  
1  
2

ENTR

0-

VARI

2-  
2-

ARRA

AP-  
2-  
2-  
2-

```
0173 26 call linchk (lun,1)
0174
0175 write (lun,28) error_bank
0176 28 format(' ',t40,'ARRAY BANK #',
0177 1 i<COMPRESS4 (error_bank)>,'. IN ERROR')
0178
0179 call LINCHK (lun,1)
0180
0181 write(lun,30) error_array
0182 30 format(' ',t40,'ARRAY #',i<compress4 (error_array)>,'. IN ERROR')
0183 endif
0184
0185 call output (lun,memory_register_0,vmemory_register0,29,29,31,'0')
0186 endif
0187
0188 call linchk (lun,1)
0189
0190 write(lun,35) memory_register_1
0191 35 format(' ',t8,'CSR1',t24,z8.8)
0192
0193 if (lib$extzv(25,3,memory_register_1).eq. 0) then
0194
0195 call output (lun,memory_register_1,vmemory_register1,28,28,28,'0')
0196 else
0197
0198 call linchk (lun,1)
0199
0200 write(lun,40) 'DIAGNOSTIC MODE'
0201 40 format(' ',t40,a)
0202 endif
0203
0204 call linchk (lun,1)
0205
0206 write(lun,45) memory_register_2
0207 45 format(' ',t8,'CSR2',t24,z8.8)
0208
0209 if (.not. diagnostic_mode) then
0210
0211 arrays_present = 0
0212
0213 do 47,i = 0,15,2
0214
0215 array_code = lib$extzv(i,2,memory_register_2)
0216
0217 if (l0016) then
0218
0219 if (array_code .eq. 3) then
0220
0221 arrays_present = arrays_present + 2
0222
0223 else if (array_code .eq. 2) then
0224
0225 arrays_present = arrays_present + 8
0226 endif
0227
0228 else if (l0011) then
0229
```

```
0230      if (array_code .eq. 1) then
0231      arrays_present = arrays_present + 1
0232
0233      else if (array_code .eq. 3) then
0234
0235      arrays_present = arrays_present + 2
0236      endif
0237      endif
0238
0239  47      continue
0240
0241      call linchk (lun,1)
0242
0243      write(lun,50) arrays_present*128
0244      format(' ',t40,'MEMORY SIZE = ',
0245  50      1 i<compress4 (arrays_present*128)>,'.K')
0246
0247      call output (lun,memory_register_2,v1memory_register2,16,16,16,'0')
0248
0249      start_address = lib$extzv (17,7,memory_register_2)
0250
0251      call linchk (lun,1)
0252
0253      write(lun,55) start_address*128
0254      format(' ',t40,'MEMORY BASE ADDRESS = ',
0255  55      1 i<compress4 (start_address*128)>,'.K')
0256      endif
0257
0258      call linchk (lun,1)
0259
0260      if (L0016) then
0261
0262      write(lun,60) 'L0016'
0263      format(' ',t40,'CONTROLLER IS ',a)
0264  60      else
0265
0266      write(lun,60) 'L0011'
0267      endif
0268
0269      return
0270      end
0271
```

PROGRAM SECTIONS

Name	Bytes	Attributes									
0 \$CODE	1271	PIC	CON	REL	LCL	SHR	EXE	RD	NOWRT	LONG	
1 \$PDATA	412	PIC	CON	REL	LCL	SHR	NOEXE	RD	NOWRT	LONG	
2 \$LOCAL	680	PIC	CON	REL	LCL	NOSHR	NOEXE	RD	WRT	LONG	
Total Space Allocated		2363									

ENTRY POINTS

Address	Type	Name
0-00000000		MS750

VARIABLES

Address	Type	Name	Address	Type	Name
2-00000000	I*4	ARRAYS_PRESENT	2-000000C4	I*4	ARRAY_CODE
2-000000B2	L*1	DIAGNOSTIC_MODE	2-00000000	I*4	ERROR_ARRAY
2-000000C0	I*4	ERROR_BANK	2-00000000	I*4	ERROR_BIT
2-0000008C	I*4	I	2-000000B3	L*1	L0011
2-000000B4	L*1	L0016	AP-00000004B	L*1	LUN
AP-00000008B	I*4	MEMORY_REGISTERS	2-00000004	I*4	MEMORY_REGISTER_0
2-00000008	I*4	MEMORY_REGISTER_1	2-0000000C	I*4	MEMORY_REGISTER_2
2-000000B8	I*4	SLOT_INDEX	2-00000000	I*4	START_ADDRESS

ARRAYS

Address	Type	Name	Bytes	Dimensions
2-00000004	I*4	BUFFER	12	(3)
2-00000010	CHAR	V1MEMORY_REGISTER0	105	(29:31)
2-00000079	CHAR	V1MEMORY_REGISTER1	34	(28:28)
2-0000009B	CHAR	V1MEMORY_REGISTER2	23	(16:16)

LABELS

Address	Label	Address	Label	Address	Label	Address	Label	Address	Label
1-0000008F	10'	1-000000A1	15'	1-000000BD	20'	**	25	0-0000022E	26
1-000000F3	30'	1-00000114	35'	1-00000125	40'	1-0000012C	45'	**	47
1-0000015D	55'	1-00000185	60'					1-000000CD	28'
								1-0000013D	50'

0002  
0003  
0004  
0005  
0006  
0007  
0008  
0009  
0010  
0011  
0012  
0013  
0014  
0015  
0016  
0017  
0018  
0019  
0020  
0021  
0022  
0023  
0024  
0025  
0026  
0027  
0028  
0029  
0030  
0031  
0032  
0033  
0034  
0035  
0036  
0037  
0038  
0039  
0040  
0041  
0042  
0043  
0044  
0045  
0046  
0047  
0048  
0049  
0050  
0051  
0052  
0053  
0054  
0055  
0056  
0057  
0058

FUNCTIONS AND SUBROUTINES REFERENCED

Type	Name	Type	Name	Type	Name	Type	Name	Type	Name		
I*4	COMPRESS4	I*4	DECODE_ECC	I*4	LIB\$EXTZV		LINCHK		MOVCL3		OUTPUT

0059  
0060  
0061  
0062  
0063  
0064  
0065  
0066  
0067  
0068  
0069  
0070  
0071  
0072  
0073  
0074  
0075  
0076  
0077  
0078  
0079  
0080  
0081  
0082  
0083  
0084  
0085  
0086  
0087  
0088  
0089  
0090  
0091  
0092  
0093  
0094  
0095  
0096  
0097  
0098  
0099  
0100  
0101  
0102  
0103  
0104  
0105  
0106  
0107  
0108  
0109  
0110  
0111  
0112  
0113  
0114  
0115

0001

N 5  
16-Sep-1984 00:07:33  
5-Sep-1984 14:01:18

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:[ERF.SRC]MEMORY.S.FOR;1

Page 45

MEMO

0116  
0117  
0118  
0119  
0120  
0121  
0122  
0123  
0124  
0125  
0126  
0127  
0128  
0129  
0130  
0131  
0132  
0133  
0134  
0135  
0136  
0137  
0138  
0139  
0140  
0141  
0142  
0143  
0144  
0145  
0146  
0147  
0148  
0149  
0150  
0151  
0152  
0153  
0154  
0155  
0156  
0157  
0158  
0159  
0160  
0161  
0162  
0163  
0164  
0165  
0166  
0167  
0168  
0169  
0170  
0171  
0172

Subroutine MS730 (lun,memory\_register\_0)

Functional description:

This routine displays the memory registers for the 11/730. The format of the buffer is as follows.

```

+-----+
|               |
|   memory csr0   |
|               |
+-----+
|               |
|   memory csr1   |
|               |
+-----+
|               |
|   memory csr2   |
|               |
+-----+

```

Implicit none

byte lun

integer\*4 memory\_register\_0

integer\*4 buffer(3)

integer\*4 memory\_csr0

integer\*4 memory\_csr1

integer\*4 memory\_csr2

equivalence (buffer(1),memory\_csr0)

equivalence (buffer(2),memory\_csr1)

equivalence (buffer(3),memory\_csr2)

logical\*1 diagnostic\_mode

integer\*4 compress4

integer\*4 decode\_ecc

integer\*4 error\_bit

integer\*4 error\_array

integer\*4 error\_bank

integer\*4 kilo\_bytes\_present

integer\*4 lib\$extzv

integer\*4 i

character\*23 v1memory\_register\_1(27:28)

data v1memory\_register\_1(27) /'MEMORY MAPPING ENABLE\*'/

data v1memory\_register\_1(28) /'ENABLE "CRD" REPORTING\*'/

character\*12 v2memory\_register\_1(30:30)

data v2memory\_register\_1(30) /'"CRD" ERROR\*'/

character\*17 v1memory\_register\_2(24:24,0:1)

data v1memory\_register\_2(24,0) /'16K RAMS PRESENT\*'/

data v1memory\_register\_2(24,1) /'64K RAMS PRESENT\*'/

call movc3 (%val(12),memory\_register\_0,buffer)

```

0059 diagnostic_mode = .false.
0060
0061 if (iand(memory_csr1,'26000000'x) .ne. 0) diagnostic_mode = .true.
0062
0063 call linchk (lun,2)
0064
0065 write(lun,10) memory_csr0
0066 10 format(/' ',t8,'CSR0',t24,z8.8)
0067
0068 if (.not. diagnostic_mode) then
0069
0070 c
0071 c 11/730 syndrome bits are inverted so...
0072 c
0073
0074 call linchk (lun,1)
0075
0076 write(lun,15) lib$extzv(0,7,not(lib$extzv(0,7,memory_csr0)))
0077 15 format(' ',t40,'ERROR SYNDROME = ',z2.2)
0078
0079 error_bit = decode_ecc (lib$extzv(0,7,not(lib$extzv(0,7,memory_csr0))))
0080
0081 call linchk (lun,1)
0082
0083 if (error_bit .eq. -1) then
0084
0085 write(lun,20) "'ECC' CODE, UNCORRECTED ERROR"
0086 else
0087
0088 write(lun,20) 'CORRECTED ERROR, BIT #',error_bit,'.'
0089 20 format(' ',t40,a,:i<compress4 (error_bit)>,:a)
0090 endif
0091
0092 error_array = lib$extzv(9,15,memory_csr0)
0093
0094 if (LIB$EXTZV(24,1,memory_csr2) .EQ. 1) then
0095 Error_bank = LIB$EXTZV(19,2,memory_csr0)
0096
0097 Else
0098 Error_bank = LIB$EXTZV(17,1,memory_csr0)
0099
0100 Endif
0101
0102 call LINCHK (lun,1)
0103 write (lun,22) error_bank
0104 22 format(' ',t40,'ARRAY BANK #',
0105 1 i<COMPRESS4 (error_bank)>,'. IN ERROR')
0106
0107 do 25,i = 0,15
0108
0109 if (lib$extzv(i,1,memory_csr2) .eq. 1) then
0110
0111 if (lib$extzv(24,1,memory_csr2) .eq. 1) then
0112
0113 error_array = error_array - 1024
0114 else
0115

```

```

0116      error_array = error_array - 256
0117      endif
0118      endif
0119
0120      if (error_array .le. 0) then
0121
0122          error_array = 1/2
0123
0124          goto 27
0125      endif
0126
0127 25      continue
0128
0129 27      call linchk (lun,1)
0130
0131      write(lun,30) error_array
0132 30      format(' ',t40,'ARRAY #',i<compress4 (error_array)>,'. IN ERROR')
0133      endif
0134
0135      call linchk (lun,1)
0136
0137      write(lun,35) memory_csr1
0138 35      format(' ',t8,'CSR1',t24,z8.8)
0139
0140      if (.not. diagnostic_mode) then
0141
0142          call output (lun,memory_csr1,v1memory_register_1,27,27,28,'0')
0143
0144          call output (lun,memory_csr1,v2memory_register_1,30,30,30,'0')
0145      else
0146
0147          call linchk (lun,1)
0148
0149      write(lun,40) 'DIAGNOSTIC MODE'
0150 40      format(' ',t40,a)
0151      endif
0152
0153      call linchk (lun,1)
0154
0155      write(lun,45) memory_csr2
0156 45      format(' ',t8,'CSR2',t24,z8.8)
0157
0158      if (.not. diagnostic_mode) then
0159
0160          kilo_bytes_present = 0
0161
0162          do 50,i = 0,15
0163
0164              if (lib$extzv(i,1,memory_csr2) .eq. 1) then
0165
0166                  if (lib$extzv(24,1,memory_csr2) .eq. 1) then
0167
0168                      kilo_bytes_present = kilo_bytes_present + 512
0169                  else
0170
0171                      kilo_bytes_present = kilo_bytes_present + 128
0172                  endif
0173              endif
0174          enddo
0175      endif

```

```
0173      endif
0174
0175      50      continue
0176
0177      call linchk (lun,1)
0178
0179      write(lun,55) kilo bytes present
0180      55      format(' ',t40,'MEMORY SIZE = ',i<compress4 (kilo_bytes_present)>,<br>
0181      1 '.K')
0182
0183      call output (lun,memory_csr2,vmemory_register_2,24,24,24,'2')
0184      endif
0185
0186      return
0187      end
```

## PROGRAM SECTIONS

Name	Bytes	Attributes
0 \$CODE	925	PIC CON REL LCL SHR EXE RD NOWRT LONG
1 \$PDATA	325	PIC CON REL LCL SHR NOEXE RD NOWRT LONG
2 \$LOCAL	572	PIC CON REL LCL NOSHR NOEXE RD WRT LONG
Total Space Allocated	1822	

## ENTRY POINTS

Address	Type	Name
0-00000000		MS730

## VARIABLES

Address	Type	Name	Address	Type	Name
2-00000068	L*1	DIAGNOSTIC_MODE	2-00000070	I*4	ERROR_ARRAY
2-00000074	I*4	ERROR_BANK	2-0000006C	I*4	ERROR_BIT
2-0000007C	I*4	I	2-00000078	I*4	KILO_BYTES_PRESENT
AP-00000004	L*1	LUN	2-00000000	I*4	MEMORY_CSR0
2-00000004	I*4	MEMORY_CSR1	2-00000008	I*4	MEMORY_CSR2
AP-00000008	I*4	MEMORY_REGISTER_0			

## ARRAYS

Address	Type	Name	Bytes	Dimensions
2-00000000	I*4	BUFFER	12	(3)
2-0000000C	CHAR	V1MEMORY_REGISTER_1	46	(27:28)
2-00000046	CHAR	V1MEMORY_REGISTER_2	34	(24:24, 0:1)
2-0000003A	CHAR	V2MEMORY_REGISTER_1	12	(30:30)

16-SEP-1984 00:07:33  
5-SEP-1984 14:01:18

VAX-11 FORTRAN V3.4-56 Page 50  
DISK&VMSMASTER:[ERF.SRC]MEMORYS.FOR;1

Address	Label	Address	Label	Address	Label	Address	Label	Address	Label	Address	Label
1-00000077	10'	1-00000089	15'	1-000000A5	20'	1-000000B5	22'	**	25	0-000001FE	27
1-000000DB	30'	1-000000FC	35'	1-0000010D	40'	1-00000114	45'	**	50	1-00000125	55'

Type	Name	Type	Name	Type	Name	Type	Name	Type	Name
I*4	COMPRESS4	I*4	DECODE_ECC	I*4	LIBSEXTZV		LINCHK		MOV3
									OUTPUT

040  
040  
040  
040  
040  
040  
040  
040  
040  
041  
041  
041  
041  
041  
041  
041  
041  
041

**PRO**

012

## ENTI



VAR.

2

1<sup>6</sup><sub>5</sub>-SEP-1984 02:07:33

VAX-11 FORTRAN V3.4-56 Page 51  
DISK8VMSMASTER:[ERF.SRC]MEMORYS.FOR;1

REM

AP.  
AP.  
AP.

ARRA

~~~~~


**LABEL**

Q

**FUN**

11

This routine displays the UVAX1 memory registers.  
The format of the memory sub packet is as follows:



```

Implicit      none
byte          lun

integer*4     memory_registers(0:16)
integer*4     error_address1
integer*4     error_address2
integer*4     loop
integer*4     compress4
integer*4     lib$extzv
integer*4     lib$insv

character*20   v1csr(0:0)           /*PARITY ERROR ENABLE*/
data          v1csr(0)

character*16   v2csr(2:2)           /*DIAGNOSTIC MODE*/
data          v2csr(2)

character*25   v3csr(14:15)         /*EXTENDED CSR READ ENABLE*/
data          v3csr(14)             /*PARITY ERROR*/
data          v3csr(15)

call linchk (lun,1)
write (lun,1)
format ('i')

do 15,loop = 1,16

if (lib$extzv(15,1,memory_registers(loop)) .eq. 1) then

call linchk (lun,1)

write(lun,5) loop,memory_registers(loop)
format('i',T8,'CSR #',i<compress4 (loop)>,t24,z8.8)

call output (lun,memory_registers(loop),v1csr,0,0,0,'0')
call output (lun,memory_registers(loop),v2csr,2,2,2,'0')

```

```
0060      error_address1 = lib$extzv (5,7,memory_registers(loop))
0061      error_address1 = lib$insv (error_address1,11,7,error_address1)
0062
0063      error_address2 = lib$extzv (5,4,memory_registers(loop))
0064      error_address1 = lib$insv (error_address2,18,4,error_address1)
0065
0066      call linchk (lun,1)
0067
0068      write(lun,10) error_address1
0069 10      format(' ',t40,'PARITY ERROR ADDRESS, ',
0070             1 i<compress4 (error_address1)>,'.K')
0071
0072      call output (lun,memory_registers(loop),v3csr,14,14,15,'0')
0073      endif
0074
0075 15      continue
0076
0077      Return
0078      End
```

## PROGRAM SECTIONS

| Name                  | Bytes | Attributes                              |
|-----------------------|-------|-----------------------------------------|
| 0 \$CODE              | 383   | PIC CON REL LCL SHR EXE RD NOWRT LONG   |
| 1 \$PDATA             | 110   | PIC CON REL LCL SHR NOEXE RD NOWRT LONG |
| 2 \$LOCAL             | 436   | PIC CON REL LCL NOSHR NOEXE RD WRT LONG |
| Total Space Allocated | 929   |                                         |

## ENTRY POINTS

| Address    | Type | Name                |
|------------|------|---------------------|
| 0-00000000 |      | MEMORY_REGISTER_UV1 |

## VARIABLES

| Address    | Type | Name           | Address      | Type | Name           |
|------------|------|----------------|--------------|------|----------------|
| 2-00000058 | I*4  | ERROR_ADDRESS1 | 2-0000005C   | I*4  | ERROR_ADDRESS2 |
| 2-00000060 | I*4  | LOOP           | AP-00000004a | L*1  | LUN            |

## ARRAYS

| Address      | Type | Name             | Bytes | Dimensions |
|--------------|------|------------------|-------|------------|
| AP-00000008a | I*4  | MEMORY_REGISTERS | 68    | (0:16)     |
| 2-00000000   | CHAR | V1CSR            | 20    | (0:0)      |
| 2-00000014   | CHAR | V2CSR            | 16    | (2:2)      |
| 2-00000024   | CHAR | V3CSR            | 50    | (14:15)    |

16-SEP-1984 00:07:33  
5-SEP-1984 14:01:18

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:[ERF.SRC]MEMORY.S.FOR;1

Page 54

| Address    | Label | Address    | Label | Address    | Label | Address | Label |
|------------|-------|------------|-------|------------|-------|---------|-------|
| 1-0000002A | 1'    | 1-0000002E | 5'    | 1-00000046 | 10'   | **      | 15    |

| Type | Name      | Type | Name      | Type | Name     | Type | Name   | Type | Name   |
|------|-----------|------|-----------|------|----------|------|--------|------|--------|
| I*4  | COMPRESS4 | I*4  | LIBSEXTZV | I*4  | LIBSINSV |      | LINCHK |      | OUTPUT |

16<sup>K</sup>-sep-1984 00:07:33  
5-sep-1984 12:01:18

VAX-11 FORTRAN V3.4-56 Page 55  
DISK\$VMSMASTER:[ERF.SRC]MEMORYS.FOR;1

MEMO

0119  
0117  
0118  
0116  
0120  
0121  
0122  
0123  
0124  
0125  
0126  
0127  
0128  
0129  
0130  
0131  
0132  
0133  
0134  
0135  
0136  
0137  
0138  
0139  
0140  
0141  
0142  
0143  
0144  
0145  
0146  
0147  
0148  
0149  
0150  
0151  
0152  
0153  
0154  
0155  
0156  
0157  
0158  
0159  
0160  
0161  
0162  
0163  
0164  
0165  
0166  
0167  
0170  
0171  
0172

Functional description:

This module maintains a list which is used to produce a display that shows where and how many memory errors have occurred. The format of the list is shown below.

|                         |
|-------------------------|
| fblink1                 |
| blink1                  |
| logging sid             |
| root node memory flink  |
| root memory node blink  |
| memory node entry count |

|                   |
|-------------------|
| fblink2           |
| blink2            |
| memory node       |
| root array flink  |
| root array blink  |
| array entry count |

|                        |
|------------------------|
| fblink3                |
| blink3                 |
| array                  |
| root array bank flink  |
| root array bank blink  |
| array bank entry count |

|         |
|---------|
| fblink4 |
| blink4  |

0059  
0060  
0061  
0062  
0063  
0064  
0065  
0066  
0067  
0068  
0069  
0070  
0071  
0072  
0073  
0074  
0075  
0076  
0077  
0078  
0079  
0080  
0081  
0082  
0083  
0084  
0085  
0086  
0087  
0088  
0089  
0090  
0091  
0092  
0093  
0094  
0095  
0096  
0097  
0098  
0099  
0100  
0101  
0102  
0103  
0104  
0105  
0106  
0107  
0108  
0109  
0110  
0111  
0112  
0113  
0114  
0115

~~~~~

array bank
root array bit flink
root array bit blink
array page entry count
fLink5
blink5
array bit
error count

```

Subroutine MEMORY_Q (search_sid,search_memory_node,
1 search_array,search_array_bank,search_array_bit)

Implicit          none
byte              lun

integer*4         buffer0(2)
integer*4         buffer1(6)
integer*4         buffer2(6)
integer*4         buffer3(6)
integer*4         buffer4(6)
integer*4         buffer5(4)
integer*4         root_logging_sid_flink
integer*4         root_logging_sid_blink


equivalence       (buffer0(1),root_logging_sid_flink)
equivalence       (buffer0(2),root_logging_sid_blink)

integer*4         flink1
integer*4         blink1
integer*4         logging_sid
integer*4         root_memory_node_flink
integer*4         root_memory_node_blink
integer*4         memory_node_entry_count

equivalence       (buffer1(1),flink1)
equivalence       (buffer1(2),blink1)
equivalence       (buffer1(3),logging_sid)
equivalence       (buffer1(4),root_memory_node_flink)
equivalence       (buffer1(5),root_memory_node_blink)
equivalence       (buffer1(6),memory_node_entry_count)

integer*4         flink2
integer*4         blink2
integer*4         memory_node

```

**A** 

0116	integer*4	root_array_flink
0117	integer*4	root_array_blink
0118	integer*4	array_entry_count
0119		
0120	equivalence	(buffer2(1),flink2)
0121	equivalence	(buffer2(2),blink2)
0122	equivalence	(buffer2(3),memory_node)
0123	equivalence	(buffer2(4),root_array_flink)
0124	equivalence	(buffer2(5),root_array_blink)
0125	equivalence	(buffer2(6),array_entry_count)
0126		
0127	integer*4	flink3
0128	integer*4	blink3
0129	integer*4	array
0130	integer*4	root_array_bank_flink
0131	integer*4	root_array_bank_blink
0132	integer*4	array_bank_entry_count
0133		
0134	equivalence	(buffer3(1),flink3)
0135	equivalence	(buffer3(2),blink3)
0136	equivalence	(buffer3(3),array)
0137	equivalence	(buffer3(4),root_array_bank_flink)
0138	equivalence	(buffer3(5),root_array_bank_blink)
0139	equivalence	(buffer3(6),array_bank_entry_count)
0140		
0141	integer*4	flink4
0142	integer*4	blink4
0143	integer*4	array_bank
0144	integer*4	root_array_bit_flink
0145	integer*4	root_array_bit_blink
0146	integer*4	array_bit_entry_count
0147		
0148	equivalence	(buffer4(1),flink4)
0149	equivalence	(buffer4(2),blink4)
0150	equivalence	(buffer4(3),array_bank)
0151	equivalence	(buffer4(4),root_array_bit_flink)
0152	equivalence	(buffer4(5),root_array_bit_blink)
0153	equivalence	(buffer4(6),array_bit_entry_count)
0154		
0155	integer*4	flink5
0156	integer*4	blink5
0157	integer*4	array_bit
0158	integer*4	error_count
0159		
0160	equivalence	(buffer5(1),flink5)
0161	equivalence	(buffer5(2),blink5)
0162	equivalence	(buffer5(3),array_bit)
0163	equivalence	(buffer5(4),error_count)
0164		
0165	integer*4	insert_blink
0166	integer*4	logging_sid_entry_count
0167	integer*4	logging_sid_entry_address
0168	integer*4	memory_node_entry_address
0169	integer*4	array_entry_address
0170	integer*4	array_bank_entry_address
0171	integer*4	array_bit_entry_address
0172	integer*4	search_sid

```
0173 integer*4 search_memory_node
0174 integer*4 search_array
0175 integer*4 search_array_bank
0176 integer*4 search_array_bit
0177 integer*4 compress4
0178 integer*4 I
0179 integer*4 J
0180 integer*4 K
0181 integer*4 L
0182 integer*4 M
0183 integer*4 lib$extzv
0184 integer*4 Root_flink
0185 integer*4 Sid_count
0186 integer*4 Node_count
0187 integer*4 Array_count
0188 integer*4 Bank_count
0189 integer*4 Bit_count
0190
0191 logical*1 lib$get_vm
0192
0193
0194 logging_sid_entry_address = root_logging_sid_flink
0195
0196 do 100,i = 1,logging_sid_entry_count
0197
0198 call movc3 (%val(24),%val(logging_sid_entry_address),buffer1)
0199
0200 if (search_sid .eq. logging_sid) then
0201
0202 5 memory_node_entry_address = root_memory_node_flink
0203
0204 do 90,j = 1,memory_node_entry_count
0205
0206 call movc3 (%val(24),%val(memory_node_entry_address),buffer2)
0207
0208 if (search_memory_node .eq. memory_node) then
0209
0210 10 array_entry_address = root_array_flink
0211
0212 do 80,k = 1,array_entry_count
0213
0214 call movc3 (%val(24),%val(array_entry_address),buffer3)
0215
0216 if (search_array .eq. array) then
0217
0218 15 array_bank_entry_address = root_array_bank_flink
0219
0220 do 70,l = 1,array_bank_entry_count
0221
0222 call movc3 (%val(24),%val(array_bank_entry_address),buffer4)
0223
0224 if (search_array_bank .eq. array_bank) then
0225
0226 20 array_bit_entry_address = root_array_bit_flink
0227
0228 do 60,m = 1,array_bit_entry_count
0229
```

```

0230      call movc3 (%val(16),%val(array_bit_entry_address),buffer5)
0231
0232      if (search_array_bit .eq. array_bit) then
0233
0234 25      error_count = error_count + 1
0235
0236      call movl (error_count,%val(array_bit_entry_address + 12))
0237
0238      return
0239      endif
0240
0241      array_bit_entry_address = flink5
0242
0243 60      continue
0244
0245      call movc5 (%val(0),,%val(0),%val(16),buffer5)
0246
0247      if (lib$get_vm(((16+7)/8)*8,array_bit_entry_address)) then
0248
0249      call insque (%val(array_bit_entry_address),
0250      1 %val(root_array_bit_blink))
0251
0252      array_bit = search_array_bit
0253
0254      call movq (array_bit,%val(array_bit_entry_address + 8))
0255
0256      array_bit_entry_count = array_bit_entry_count + 1
0257
0258      call movl (array_bit_entry_count,%val(array_bank_entry_address + 20))
0259
0260      goto 25
0261      endif
0262
0263      return
0264      endif
0265
0266      insert_blink = blink4
0267
0268      if (array_bank .gt. search_array_bank) goto 75
0269
0270      array_bank_entry_address = flink4
0271
0272 70      continue
0273
0274      insert_blink = root_array_bank_blink
0275
0276 75      call movc5 (%val(0),,%val(0),%val(24),buffer4)
0277
0278      if (lib$get_vm(((24+7)/8)*8,array_bank_entry_address)) then
0279
0280      call insque (%val(array_bank_entry_address),%val(insert_blink))
0281
0282      array_bank = search_array_bank
0283
0284      root_array_bit_flink = array_bank_entry_address + 12
0285
0286      root_array_bit_blink = root_array_bit_flink

```

```
0287  
0288      call movc3 (%val(16),array_bank,%val(array_bank_entry_address + 8))  
0289  
0290      array_bank_entry_count = array_bank_entry_count + 1  
0291  
0292      call movl (array_bank_entry_count,%val(array_entry_address + 20))  
0293  
0294      goto 20  
0295  endif  
0296  
0297      return  
0298  endif  
0299  
0300      insert_blink = blink3  
0301  
0302      if (array .gt. search_array) goto 85  
0303  
0304      array_entry_address = flink3  
0305  
80      continue  
0306  
0307      insert_blink = root_array_blink  
0308  
85      call movc5 (%val(0),,%val(0),%val(24),buffer3)  
0310  
0311      if (lib$get_vm(((24+7)/8)*8,array_entry_address)) then  
0312  
0313      call insque (%val(array_entry_address),%val(insert_blink))  
0314  
0315      array = search_array  
0316  
0317      root_array_bank_flink = array_entry_address + 12  
0318  
0319      root_array_bank_blink = root_array_bank_flink  
0320  
0321      call movc3 (%val(16),array,%val(array_entry_address + 8))  
0322  
0323      array_entry_count = array_entry_count + 1  
0324  
0325      call movl (array_entry_count,%val(memory_node_entry_address + 20))  
0326  
0327      goto 15  
0328  endif  
0329  
0330      return  
0331  endif  
0332  
0333      insert_blink = blink2  
0334  
0335      if (memory_node .gt. search_memory_node) goto 95  
0336  
0337      memory_node_entry_address = flink2  
0338  
90      continue  
0339  
0340      insert_blink = root_memory_node_blink  
0341  
0342  
0343
```

```
0151  
0152  
0160  
0161  
0162  
0163  
0164  
0165  
0166  
0167  
0168  
0169  
0170  
0171  
0172  
0173  
0174  
0175  
0176  
0177  
0178  
0179  
0180  
0181  
0182  
0183  
0184  
0185  
0186  
0187  
0188  
0189  
0190  
0191  
0192  
0193  
0194  
0195  
0196  
0197  
0198  
0199  
0200  
0201  
0202  
0203  
0204
```

```
0344 95 call movc5 (%val(0),,%val(0),%val(24),buffer2)
0345
0346 if (lib$get_vm(((24+7)/8)*8,memory_node_entry_address)) then
0347
0348 call insque (%val(memory_node_entry_address),%val(insert_blink))
0349
0350 memory_node = search_memory_node
0351
0352 root_array_flink = memory_node_entry_address + 12
0353
0354 root_array_blink = root_array_flink
0355
0356 call movc3 (%val(16),memory_node,%val(memory_node_entry_address + 8))
0357
0358 memory_node_entry_count = memory_node_entry_count + 1
0359
0360 call movl (memory_node_entry_count,
0361 1 %val(logging_sid_entry_address + 20))
0362
0363 goto 10
0364 endif
0365
0366 return
0367 endif
0368
0369 logging_sid_entry_address = flink1
0370
0371 100 continue
0372
0373 call movc5 (%val(0),,%val(0),%val(24),buffer1)
0374
0375 if (logging_sid_entry_count .eq. 0) then
0376
0377 root_logging_sid_flink = %loc(root_logging_sid_flink)
0378
0379 root_logging_sid_blink = root_logging_sid_flink
0380 endif
0381
0382 if (lib$get_vm(((24+7)/8)*8,logging_sid_entry_address)) then
0383
0384 call insque (%val(logging_sid_entry_address),
0385 1 %val(root_logging_sid_blink))
0386
0387 logging_sid = search_sid
0388
0389 root_memory_node_flink = logging_sid_entry_address + 12
0390
0391 root_memory_node_blink = root_memory_node_flink
0392
0393 call movc3 (%val(16),logging_sid,%val(logging_sid_entry_address + 8))
0394
0395 logging_sid_entry_count = logging_sid_entry_count + 1
0396
0397 goto 5
0398 endif
0399
0400 return
```

```

0401
0402 C
0403 C This routine returns the root flink and the number of entries for the
0404 C memory information queue.
0405 C
0406 Entry GET_MEMORY_Q_INFO (root_flink,sid_count,node_count,array_count,
0407 1 bank_count,bit_count)
0408
0409 Root_flink = root_logging_sid_flink
0410 Sid_count = logging_sid_entry_count
0411 Node_count = memory_node_entry_count
0412 Array_count = array_entry_count
0413 Bank_count = array_bank_entry_count
0414 Bit_count = array_bit_entry_count
0415
0416 Return
0417
0418 End

```

## PROGRAM SECTIONS

Name	Bytes	Attributes
0 \$CODE	925	PIC CON REL LCL SHR EXE RD NOWRT LONG
1 \$PDATA	8	PIC CON REL LCL SHR NOEXE RD NOWRT LONG
2 \$LOCAL	608	PIC CON REL LCL NOSHR NOEXE RD WRT LONG
Total Space Allocated	1541	

## ENTRY POINTS

Address	Type	Name	Address	Type	Name
0-00000375		GET_MEMORY_Q_INFO	0-00000000		MEMORY_Q

## VARIABLES

Address	Type	Name	Address	Type	Name
2-00000030	1*4	ARRAY	2-00000018	1*4	ARRAY_BANK
2-00000090	1*4	ARRAY_BANK_ENTRY_ADDRESS	2-0000003C	1*4	ARRAY_BANK_ENTRY_COUNT
2-00000008	1*4	ARRAY_BIT	2-00000094	1*4	ARRAY_BIT_ENTRY_ADDRESS
2-00000024	1*4	ARRAY_BIT_ENTRY_COUNT	AP-00000010a	1*4	ARRAY_COUNT
2-0000008C	1*4	ARRAY_ENTRY_ADDRESS	2-00000054	1*4	ARRAY_ENTRY_COUNT
AP-00000014a	1*4	BANK_COUNT	AP-00000018a	1*4	BIT_COUNT
2-0000005C	1*4	BLINK1	2-00000044	1*4	BLINK2
2-0000002C	1*4	BLINK3	2-00000014	1*4	BLINK4
2-00000004	1*4	BLINK5	2-00000098	1*4	COMPRESS4
2-0000000C	1*4	ERROR_COUNT	2-00000058	1*4	FLINK1
2-00000040	1*4	FLINK2	2-00000028	1*4	FLINK3
2-00000010	1*4	FLINK4	2-00000000	1*4	FLINK5
2-0000009C	1*4	I	2-0000007C	1*4	INSERT_BLINK

2-0000000A4	1:4	K
2-0000000B0	1:4	LIBSEXTZV
2-0000000B4	1:4	LOGGING_SID_ENTRY_ADDRESS
2-000000078	1:1	LUN
2-000000048	1:4	MEMORY_NODE
2-00000006C	1:4	MEMORY_NODE_ENTRY_COUNT
2-000000038	1:4	ROOT_ARRAY_BANK_BLINK
2-000000020	1:4	ROOT_ARRAY_BIT_BLINK
2-000000050	1:4	ROOT_ARRAY_BLINK
AP-000000048	1:4	ROOT_FLINK
2-000000070	1:4	ROOT_LOGGING_SID_FLINK
2-000000064	1:4	ROOT_MEMORY_NODE_FLINK
AP-0000000108	1:4	SEARCH_ARRAY_BANK
AP-0000000088	1:4	SEARCH_MEMORY_NODE
AP-0000000088	1:4	SID_COUNT

Type	Name	Type	Name	Type	Name	Type	Name	Type	Name	Type	Name
	INSQUE	L*1	LIB\$GET_VM		MOV C3		MOV C5		MOV L		MOV Q

0001

H 7  
16-Sep-1984 00:07:33  
5-Sep-1984 12:01:18

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:[ERF.SRC]MEMORYS.FOR;1 Page 65

000  
000  
000  
000  
000  
000  
000  
000  
001  
001  
001  
001  
001  
001  
001  
001  
001  
001  
002  
002  
002  
002  
002  
002  
002  
002  
002  
002  
003  
003  
003  
003  
003  
003  
003  
003  
003  
004  
004  
004  
004  
004  
004  
004  
004  
005  
005  
005  
005  
005  
005  
005  
005

```

0002      C++
0003      Functional description:
0004
0005      This entry point is used to display the memory error occurrence list
0006      built by memory_q.
0007
0008
0009      Subroutine MEMORY_DISPLAY (lun)
0010
0011      Implicit      none
0012
0013      integer*4     buffer0(2)
0014      integer*4     buffer1(6)
0015      integer*4     buffer2(6)
0016      integer*4     buffer3(6)
0017      integer*4     buffer4(6)
0018      integer*4     buffer5(4)
0019      integer*4     root_logging_sid_flink
0020      integer*4     root_logging_sid_blink
0021
0022      equivalence   (buffer0(1),root_logging_sid_flink)
0023      equivalence   (buffer0(2),root_logging_sid_blink)
0024
0025      integer*4     flink1
0026      integer*4     blink1
0027      integer*4     logging_sid
0028      integer*4     root_memory_node_flink
0029      integer*4     root_memory_node_blink
0030      integer*4     memory_node_entry_count
0031
0032      equivalence   (buffer1(1),flink1)
0033      equivalence   (buffer1(2),blink1)
0034      equivalence   (buffer1(3),logging_sid)
0035      equivalence   (buffer1(4),root_memory_node_flink)
0036      equivalence   (buffer1(5),root_memory_node_blink)
0037      equivalence   (buffer1(6),memory_node_entry_count)
0038
0039      integer*4     flink2
0040      integer*4     blink2
0041      integer*4     memory_node
0042      integer*4     root_array_flink
0043      integer*4     root_array_blink
0044      integer*4     array_entry_count
0045
0046      equivalence   (buffer2(1),flink2)
0047      equivalence   (buffer2(2),blink2)
0048      equivalence   (buffer2(3),memory_node)
0049      equivalence   (buffer2(4),root_array_flink)
0050      equivalence   (buffer2(5),root_array_blink)
0051      equivalence   (buffer2(6),array_entry_count)
0052
0053      integer*4     flink3
0054      integer*4     blink3
0055      integer*4     array
0056      integer*4     root_array_bank_flink
0057      integer*4     root_array_bank_blink
0058      integer*4     array_bank_entry_count

```

```
0059
0060      equivalence      (buffer3(1),flink3)
0061      equivalence      (buffer3(2),blink3)
0062      equivalence      (buffer3(3),array)
0063      equivalence      (buffer3(4),root_array_bank_flink)
0064      equivalence      (buffer3(5),root_array_bank_blink)
0065      equivalence      (buffer3(6),array_bank_entry_count)
0066
0067      integer*4         flink4
0068      integer*4         blink4
0069      integer*4         array_bank
0070      integer*4         root_array_bit_flink
0071      integer*4         root_array_bit_blink
0072      integer*4         array_bit_entry_count
0073
0074      equivalence      (buffer4(1),flink4)
0075      equivalence      (buffer4(2),blink4)
0076      equivalence      (buffer4(3),array_bank)
0077      equivalence      (buffer4(4),root_array_bit_flink)
0078      equivalence      (buffer4(5),root_array_bit_blink)
0079      equivalence      (buffer4(6),array_bit_entry_count)
0080
0081      integer*4         flink5
0082      integer*4         blink5
0083      integer*4         array_bit
0084      integer*4         error_count
0085
0086      equivalence      (buffer5(1),flink5)
0087      equivalence      (buffer5(2),blink5)
0088      equivalence      (buffer5(3),array_bit)
0089      equivalence      (buffer5(4),error_count)
0090
0091      integer*4         insert_blink
0092      integer*4         logging_sid_entry_count
0093      integer*4         logging_sid_entry_address
0094      integer*4         memory_node_entry_address
0095      integer*4         array_entry_address
0096      integer*4         array_bank_entry_address
0097      integer*4         array_bit_entry_address
0098      integer*4         search_sid
0099      integer*4         search_memory_node
0100      integer*4         search_array
0101      integer*4         search_array_bank
0102      integer*4         search_array_bit
0103      integer*4         I
0104      integer*4         J
0105      integer*4         K
0106      integer*4         L
0107      integer*4         M
0108      integer*4         lib$extzv
0109      integer*4         compress4
0110
0111      byte              lun
0112
0113      C
0114      C Get the root flink and neccessary entry counts fort the memory information
0115      C queue.
```

011  
011  
011  
011  
011  
012  
012  
012  
012  
018  
028  
028  
028  
028  
029  
029  
029  
029  
029  
029  
029  
030  
030  
030  
030  
030  
030  
030  
030  
031  
031  
031  
031  
031  
031  
031  
031  
031  
032  
032  
032  
032  
032  
032  
032  
032

```
0116 C
0117 call GET_MEMORY_Q_INFO (root_logging_sid_flink,logging_sid_entry_count,
0118 1 memory_node_entry_count,array_entry_count,array_bank_entry_count,
0119 2 array_bit_entry_count)
0120
0121 logging_sid_entry_address = root_logging_sid_flink
0122
0123 do 200,i = 1,logging_sid_entry_count
0124
0125 call movc3 (%val(24),%val(logging_sid_entry_address),buffer1)
0126
0127 call frctof (lun)
0128
0129 call linchk (lun,2)
0130
0131 110 write(lun,110) logging_sid
0132 format(/' ', 'SUMMARY OF MEMORY ERRORS LOGGED BY SID ',z8.8)
0133
0134 memory_node_entry_address = root_memory_node_flink
0135
0136 do 190,j = 1,memory_node_entry_count
0137
0138 call movc3 (%val(24),%val(memory_node_entry_address),buffer2)
0139
0140 call linchk (lun,5)
0141
0142 if (lib$extzv(24,8,logging_sid) .eq. 1) then
0143
0144 115 write(lun,115) 'TR #',memory_node
0145 format(/' ', 'CONTROLLER AT ',a,i<compress4 (memory_node)>,'.')
0146
0147 else if (lib$extzv(24,8,logging_sid) .eq. 2) then
0148
0149 write(lun,115) 'SLOT INDEX #',memory_node
0150 endif
0151
0152 write(lun,117) 'ARRAY#','BIT#','BANK','CORRECTED','FATAL',
0153 1 'ERRORS', 'ERRORS'
0154 117 format(/' ',t8,a,t16,a,t24,a,t35,a,t50,a/,
0155 1 t37,a,t50,a)
0156
0157 array_entry_address = root_array_flink
0158
0159 do 180,k = 1,array_entry_count
0160
0161 call movc3 (%val(24),%val(array_entry_address),buffer3)
0162
0163 array_bank_entry_address = root_array_bank_flink
0164
0165 do 170,l = 1,array_bank_entry_count
0166
0167 call movc3 (%val(24),%val(array_bank_entry_address),buffer4)
0168
0169 array_bit_entry_address = root_array_bit_flink
0170
0171 do 160,m = 1,array_bit_entry_count
0172
```

[illegible]

```
0230      195      logging_sid_entry_address = flink1
0231
0232      200      continue
0233
0234      return
0235
0236      end
0237
```

## PROGRAM SECTIONS

Name	Bytes	Attributes
0 \$CODE	916	PIC CON REL LCL SHR EXE RD NOWRT LONG
1 \$PDATA	286	PIC CON REL LCL SHR NOEXE RD NOWRT LONG
2 \$LOCAL	424	PIC CON REL LCL NOSHR NOEXE RD WRT LONG
Total Space Allocated	1626	

## ENTRY POINTS

```

Address  Type  Name
0-00000000      MEMORY_DISPLAY

```

## VARIABLES

Address	Type	Name	Address	Type	Name
2-00000030	I*4	ARRAY	2-00000018	I*4	ARRAY_BANK
2-0000008C	I*4	ARRAY_BANK_ENTRY_ADDRESS	2-0000003C	I*4	ARRAY_BANK_ENTRY_COUNT
2-00000008	I*4	ARRAY_BIT	2-00000090	I*4	ARRAY_BIT_ENTRY_ADDRESS
2-00000024	I*4	ARRAY_BIT_ENTRY_COUNT	2-00000088	I*4	ARRAY_ENTRY_ADDRESS
2-00000054	I*4	ARRAY_ENTRY_COUNT	2-0000005C	I*4	BLINK1
2-00000044	I*4	BLINK2	2-0000002C	I*4	BLINK3
2-00000014	I*4	BLINK4	2-00000004	I*4	BLINK5
2-0000000C	I*4	ERROR_COUNT	2-00000058	I*4	FLINK1
2-00000040	I*4	FLINK2	2-00000028	I*4	FLINK3
2-00000010	I*4	FLINK4	2-00000000	I*4	FLINK5
2-000000A8	I*4	I	2-00000078	I*4	INSERT_BLINK
2-000000AC	I*4	J	2-000000B0	I*4	K
2-000000B4	I*4	L	2-00000060	I*4	LOGGING_SID
2-00000080	I*4	LOGGING_SID_ENTRY_ADDRESS	2-0000007C	I*4	LOGGING_SID_ENTRY_COUNT
AP-00000048	L*1	LUN	2-000000B8	I*4	M
2-00000048	I*4	MEMORY_NODE	2-00000084	I*4	MEMORY_NODE_ENTRY_ADDRESS
2-0000006C	I*4	MEMORY_NODE_ENTRY_COUNT	2-00000038	I*4	ROOT_ARRAY_BANK_BLINK
2-00000034	I*4	ROOT_ARRAY_BANK_FLINK	2-00000020	I*4	ROOT_ARRAY_BIT_BLINK
2-0000001C	I*4	ROOT_ARRAY_BIT_FLINK	2-00000050	I*4	ROOT_ARRAY_BLINK
2-0000004C	I*4	ROOT_ARRAY_FLINK	2-00000074	I*4	ROOT_LOGGING_SID_BLINK
2-00000070	I*4	ROOT_LOGGING_SID_FLINK	2-00000068	I*4	ROOT_MEMORY_NODE_BLINK
2-00000064	I*4	ROOT_MEMORY_NODE_FLINK	2-0000009C	I*4	SEARCH_ARRAY
2-000000A0	I*4	SEARCH_ARRAY_BANK	2-000000A4	I*4	SEARCH_ARRAY_BIT

**MF T**

044  
044  
044  
044  
044  
044  
045  
045  
045  
045  
045  
045  
045  
045  
045  
046  
046  
046  
046  
046  
046  
046  
046  
046  
047  
047  
047  
047  
047  
047  
047  
047  
047  
048  
048  
048  
048  
048  
048  
048  
048  
048  
049  
049  
049  
049  
049  
049  
049  
049  
049  
050

2-00000094 I-4 SEARCH\_SID

```
Run Time: 34.31 seconds
Elapsed Time: 68.12 seconds
Page Faults: 470
Dynamic Memory: 236 pages
```

050  
050  
050  
050  
050  
050  
050  
050  
050  
051  
051  
051  
051  
051  
051  
051  
051  
051  
052  
052  
052  
052  
052  
052  
052  
052  
052  
052  
053  
053  
053  
053  
053  
053  
053  
053  
054  
054  
054  
054  
054  
054  
054  
054  
054  
054  
055  
055  
055  
055  
055  
055  
055

0151

DIGITAL EQUIPMENT CORPORATION  
CONFIDENTIAL AND PROPRIETARY